

Function Button

Microphone
Indicator LED

. Press and hold the Function Button for about 3 seconds, blue lights flashing to "power on"
. Press and hold the Function Button for about 5 seconds, blue lights flashing to "power off"

. Press the Function Button of the two sides Earbuds for about 3 seconds at the same time, the red and blue lights flicker alternately, so the Earbud center TWS pairing mode.; double-click any side on/off button, it becomes main machine which is the R channel. The other side becomes the vice machine. The TWS headphones are collected successfully when one side blue light flashes and the red and blue light flashes alternately the other side. Then open your mobile phone Bluetooth to search for the connection. Prompt sounds "power on"-Pairing- your device is connected

. Connect with mobile phone successfully Prompt sounds your device is connected"Blue light flashes

. Playing music: Short press to play and Blue light flashes (Short press to pause)
. L double click for previous song
. R double click for next song L double click for previous song

. Answer calls Short press to reply call (Phone state Short press to hang up the)
. Rejection of calls Press L or R for two seconds

. If low power alarm sounds "Battery Low" and Red light flashing
. Low power shutdown alarm sounds "power off" and Red light flashes three times
. Charging Red light is on once charging if Charging saturation Turn on the blue light for about 30 seconds.



Earbuds power supply

Charger outlet

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.