

Sound Bar

S18L

User Manual


Sound Bar User Manual

Operating Introduction

a. Place the Soundbar on flat surfaces. Alternatively, you can wall mount the Soundbar with the screws provided. This Soundbar can be connected to play sound in three different ways:

1. Connect to your Television Headphone Socket
2. Connect to any Bluetooth enabled device
3. Connect to a USB Drive (stick) loaded with music files

b. Cable and external devices connection arrangements:



EN	EN
LINE IN	LINE IN
DC 19V IN	DC 19V IN

c. At the right hand side of the Sound Bar are the manual control buttons:



EN	EN
Hold down φ/MODE for Power On/Standby .	Hold down φ/MODE for Power On/Standby .
Press φ/MODE to change the mode between: Line In -> Bluetooth -> USB Drive	Press φ/MODE to change the mode between: Line In -> Bluetooth -> USB Drive
Press/Hold down ▶/II / MUTE for Pause/Play . (USB Drive)	Press/Hold down ▶/II / MUTE for Pause/Play . (USB Drive)
Press/Hold down ▶/II / MUTE for Mute / No Mute . (Line In)	Press/Hold down ▶/II / MUTE for Mute / No Mute . (Line In)
Hold down VOL+ /▶▶ for Volume up .	Hold down VOL+ /▶▶ for Volume up .
Press VOL+ /▶▶ for Next USB Drive Song .	Press VOL+ /▶▶ for Next USB Drive Song .
Hold down VOL- /◀◀ for Volume down .	Hold down VOL- /◀◀ for Volume down .
Press VOL- /◀◀ for Previous Drive Song .	Press VOL- /◀◀ for Previous Drive Song .

d. Front LED Display showing the different input modes

	Line In
	Bluetooth
	USB drive when USB Drive in (no USB drive will flash Led and skip to next mode in seconds)

Front indicator Lights:

Red dot: Soundbar in standby

bt font: Flashing means Bluetooth is waiting to pair with your Bluetooth enabled device.

bt lit and static means a Bluetooth device is paired.

e. Remote control buttons



	Power on / Standby
	Mute
	Volume up
	Volume down
	Previous (USB drive audio)
	Next (USB drive audio)
	Play/Pause(USB drive audio)
	Repeat (USB drive audio)
	Equalizer selection
	Mode Audio source selection

* EQ (Equalizer) Preset Music tone settings to suit personal taste

While playing music continually press the EQ button to toggle between the different presets

Display	EQ mode	LED Indicators
Eq1	News	Red
Eq2	Bass	Green
Eq3	Surround	Blue

Technical Specification

Power/Amps: Input: AC110~240V, 50/60Hz, Output: DC19V, 1.5A

Power consumption: 30W

Max output power: 40W

Soundbar measurement: 80cm x 6cm x 6cm

Bluetooth name: S18L

Packing List

- . Sound bar
- . Manual
- . 3.5mm to 3.5MM audio cable
- . Screws x 2
- . Remote control
- . Mains Power supply

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.