

Gaming headset


Model:C08W

Manual Bluetooth Headphone LED Indicator Description:


| | |
|--------------------|--|
| Pairing status | Blue and red lights flash alternately |
| Power on | Blue light stays on and then enters pairing status |
| Stand by mode | Blue light stays on |
| Low battery status | Red light flashes 3 times for 5 seconds |
| Charging mode | Charging red light is on, full red light is off |

Basic Bluetooth Headphone Button Operation

Power on:

Long press the power button  for 3 seconds, the blue light of the headphone stays on for 2 seconds and then turns on. After turning on, it automatically enters the pairing state, and the Bluetooth indicator light flashes alternately with red and blue lights.


Power off:

Long press the button  for 3 seconds to turn off, the red light stays on for 2 seconds and then goes out.

Volume adjustment:





Slide the potentiometer to adjust the volume. The volume increases upwards and decreases downwards.

Song switching:

Double-click the button  to skip to the next song to play.

Triple-click the button  to skip to the previous song to play.

Play/Pause/Answer phone:

| |
|--|
| Short press the button  when music is playing to pause the music. |
| Short press the button  when music is paused to play the music. |
| Short press the button  when there is an incoming call to answer the phone. |
| Short press the button  during a call to hang up the current call. |

Double-click the button  when there is an incoming call to reject the call.

Microphone on and mute:

1. Click the M button to disable the microphone. The microphone indicator light goes out and there is a voice prompt.
2. To resume using the microphone, click the M button while the microphone is muted to resume using the microphone. The microphone indicator light is on and there is a voice prompt. (Note: You can also disable/restore the use of the microphone when not in a call)

Headphone charging:

When the battery is low, please use the USB charging cable to charge for about 2 hours. The headphones will automatically turn off during the charging process. The red indicator light stays on when charging and goes out when fully charged.

Battery capacity status:

When the headphones are connected to an IOS device, the current headphone battery status is displayed in the upper right corner of the screen.

Line-in mode:

Insert the audio cable and the headphones will automatically turn off. In wired mode, you can use the microphone on the headphones to make calls. Note: When using wired mode, Bluetooth cannot be turned on normally. You need to unplug the audio cable before you can turn it on and use it normally.

Bluetooth mode connection:

When the headphones are connected to the transmitter, long press the M button on the headphones for three seconds to enter (Bluetooth mode), and the red and blue lights flash alternately. Turn on the Bluetooth function of the Bluetooth device and search for the Bluetooth device name of the headphones: PG-06. Click PG-06 to connect. After successful connection, the blue light stays on and flashes slowly when music is playing. Note: If the headphones are turned on in Bluetooth mode, there is no need to long press the M button on the headphones for three seconds.

Headphone and transmitter connection:

When the headphones are connected to a mobile phone, long press the M button on the headphones for three seconds to switch to Dongle mode, and the headphones actively connect to the transmitter. Note: 1. If the headphones

are turned on in Dongle mode, they will automatically connect to the transmitter without long pressing the headphones for three seconds. 2. If the transmitter cannot connect to the headphones, press the transmitter button 8 times and then simultaneously long press the power button and M button on the headphones for 3 seconds to restore factory settings.

Automatic shutdown and Reconnection beyond distance:


When the headphones are out of range and disconnected from a valid distance. Automatically reconnect within 5 minutes of returning to Bluetooth range. If you do not return to a valid Bluetooth connection range within 5 minutes, the headphones will automatically turn off.

Transmitter mode connection

Bluetooth transmitter LED indicator description


| | |
|------------------------|----------------------------|
| Pairing status: | Cyan light flashes quickly |
| Connection successful: | Cyan light stays on |
| Reconnection status: | Cyan light flashes quickly |

Connecting to a PC for use:

1. Insert the transmitter into the PC's USB connector. The PC will automatically install the driver and the transmitter's cyan light will flash quickly and automatically enter pairing mode.
2. Long press the headphone button  for 3 seconds. After turning on, it will prompt (Dongle mode) and automatically enter pairing mode. If it prompts (Bluetooth mode) after turning on, long press the M button for 3 seconds to switch to Dongle mode.
3. When the Bluetooth indicator light on the headphones is on and the transmitter indicator light is on, it means that the headphones and transmitter are connected and you can listen to music, play games, voice chat, video chat, etc.
4. Note: If the headphones and microphone cannot be used, please set PG-06 as the microphone input and audio output device.

Connecting to PS4, PS4Pro, PS5

1. Turn on the PS4 game console
2. Insert the transmitter into the USB port of the PS4. The PS4 will automatically install the driver. The transmitter's blue and orange lights will flash alternately and automatically enter pairing mode.

3. Press and hold the power button  on the headset for 3 seconds. After turning on, it will prompt (Dongle mode) and automatically enter pairing mode. If it prompts (Bluetooth mode) after turning on, press and hold the M button for 3 seconds to switch to Dongle mode.
4. When the Bluetooth indicator light on the headset is solid blue and the indicator light on the transmitter is solid blue, it means that the headset and transmitter are connected.
5. When the PG-06 wireless headset is detected, navigate to the “Settings” menu.
6. Highlight and select the “Settings” menu option.
7. Scroll down to “Peripherals” and select it.
8. Scroll down to “Audio Devices” and select it.
9. Set “Input Device” to “PG-06” wireless headset.
10. Set “Output Device” to “PG-06” wireless headset.
11. Select “Output to Headphones” and choose “All Audio”.

Headphone actively reconnects to the transmitter function

In transmitter mode, the headphones actively reconnect to the transmitter when turned on.

Initiate an active connection between the transmitter and the headphones.

If the transmitter and headphones cannot connect, press the transmitter button 8 times and simultaneously hold down the headphone power button and M button for 3 seconds.

Switching between Bluetooth mode and transmitter mode

1. In Bluetooth mode, press and hold the M key for 3 seconds to switch to transmitter mode. The headphones will actively connect to the transmitter.
2. In transmitter mode, press and hold the M key for 3 seconds to switch to Bluetooth mode. The headphones will actively enter Bluetooth reconnection or pairing status.

Headphone parameters

| | |
|--------------------------|----------------------------|
| Bluetooth version | Bluetooth receiver (BT5.0) |
| Bluetooth protocol | A2DP, HFP, HSP, AVRCP |
| Reception distance | 8-10 meters |
| Speaker impedance | 32Ω±15% |
| Speaker sensitivity | 112±3dB at 1K HZ |
| Frequency response range | 20 HZ—20K HZ |

| | |
|------------------|---------|
| Charging voltage | DC5V |
| Charging current | 300mA |
| Working voltage | 3.7V |
| Working current | 13-38mA |

Transmitter specifications and parameters

| | |
|--------------------------|-----------------------|
| Input | USB2.0 |
| Frequency response range | 20HZ—20KHZ |
| Bluetooth protocol | A2DP, HFP, HSP, AVRCP |
| Transmission distance | 10 meters |
| Working voltage | 5V |
| Working current | 15mA |

Packaging list

1. Bluetooth headset
2. Charging cable
3. Audio cable
4. User manual
5. USB transmitter

Warm Tips:

1. Use a 5V 1A charger to charge the headphones. Charging the headphones with a charger with a voltage that is too high may damage the headphones.
2. When the headphones have not been used for more than 3 months, they need to be charged before use.
3. When not in use for a long time, it is recommended to charge the headphones once every 3 months to better protect the battery.
4. Please fully charge the headphones before using them for the first time.

Caution:

1. Do not place the headphones in a high temperature environment, including direct sunlight.
2. Do not place the headphones near a fire source or other overheated environment.
3. Do not place the headphones in a damp or submerged in liquid, keep the headphones dry.
4. Except for the provided charging cable, do not attempt to charge the headphones in any other way.
5. Do not disassemble the headphones, and do not attempt to repair or modify the headphones in any way.
6. Please be aware of excessive dropping, impact, scratching or other actions that may affect the function of the headphones. If there is any damage, such as dents, punctures, tears, deformation or corrosion, please stop using the headphones immediately and contact the seller or contact us through the contact information on the warranty card.

7. If the headphones produce an abnormal odor, are higher than normal temperature, or have abnormal changes in color or shape, please stop using the headphones immediately and contact the seller or contact us through the contact information on the warranty card.

FCC Caution.

(1)§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

According to §15.247(e)(i) and §1.1307(b)(1), systems operating under the provisions of this section shall be operated in a manner that ensures that the public is not exposed to radio frequency energy level in excess of the Commission's guidelines.

According to KDB 447498 (2)(a)(i)