



hoco.premium
product**Instruction Manual
ES62**

We are very glad that you purchase hoco wireless Earphones!
We hope it brings you fun and enjoy!

Earphones Overview

EN

**How to Use**

1. Press and hold **F** for 3 seconds until the red and blue LEDs flash alternately.
2. Turn on the BT function of your mobile device.
3. Search for and select "HOCO ES62".
4. The red light is always on when charging, and the blue light is on when fully charged. Click the F button to display the power.

Earphones Controls

Function	Operation
Power On / Power Off	Press and hold F for 3 seconds
Play / Pause	Press II
Volume+ / -	Press + / -
Next / Previous Track	Press and hold + / - for 2 seconds
Answer / Hang Up	Press II
Reject	Press and hold II for 2 seconds
Redial	Double press II
Wireless/TF playback mode switching	Triple click F
Switch between Chinese and English	Double click F in unpaired mode

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Website

Make something you love.