



Master switch: shift to open gear to adjust frequency
Switch: Click On, click Off
A key 1: corresponds to A motor socket, and the motor is in forward rotation.
F key 1: corresponding to A motor socket, the motor is in forward rotation.
Key 2: Corresponding to A motor socket, motor reversal. F key 2: corresponding to A motor socket, motor reversal. Key 1: Corresponding to A motor socket, the motor is turning forward. G key 1: corresponding to A motor socket, motor forward button 2: corresponding to A motor socket, motor reversal. G key 2: corresponding to A motor socket, motor reversal. Key 1: Corresponding to A motor socket, the motor is turning forward. H key 1: corresponding to A motor socket, the motor is in forward rotation. Key 2: Corresponding to A motor socket, motor reversal. H key 2: corresponding to A motor socket, motor reversal. Key 1: Corresponding to A motor socket, the motor is turning forward. I key 1: corresponds to A motor socket, motor forward button 2: corresponds to A motor socket, motor reverse. Key 2 of I: corresponds to A motor socket, and key 1 of motor reversal: corresponds to A motor socket, and the motor is in forward rotation. J key 1: corresponding to A motor socket, motor forward button 2: corresponding to A motor socket, motor reversal. J key 2: corresponding to A motor socket, motor reversal

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Back of receiving box



Two white lights, two yellow lights

Two red light

Receiver front



The above arrows are all motor jacks

Main switch



MicroUSB Charging mouth