

MLP-T03
小马宝莉芭蕾系列半入耳无线蓝牙耳机
使用说明书

包装清单

产品参数

充电指南

产品操作说明

功能键操作

产品中有害物质名称及含量

保修声明

MLP-T03
My Little Pony Ballet Series semi-in-ear BT Earbuds
instruction manual

Packing list

Product specifications

Charging Guide

Product operation instructions

Function key operation

Names And Contents Of Hazardous Substances In Products

Warranty Statement

MLP-T03
My Little Pony Ballet Series semi-in-ear BT Earbuds
instruction manual

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.