



Baby carriage remote control product manual

2.4G wireless transmitter remote control

Product Type:HH-672Y

Product Configuration:

Battery Specification: 1.5V (AAA)* 2

Section Operating Voltage:DC2.0-3.6V

Quiescent DC:0.5uA

Modulation Mode:GFSK

Transmission frequency:2.400-2.483GHz



This remote control shares 6 units at 2.419GHz, 2.425GHz, 2.445GHz, 2.450GHz, 2.470GHz, and 2.474GHz

Frequency point. When conducting fixed frequency testing, select high, medium, and low frequency points for testing.

Simultaneously press the three buttons "front+rear+right", load the battery and power it on to enter the fixed frequency testing mode. By default, enter mode 1, fixed frequency

Transmission mode, frequency point 2.474GHz, and LED1 constantly lights up for prompt.

Afterwards, release all buttons and press the "swing" button to switch modes.

1. Press the "swing" button for the first time to switch to mode 2: fixed frequency transmission mode, with a frequency point of 2.445GHz and LED2 constantly on.

2. Press the "swing" button for the second time to switch to mode 3: fixed frequency transmission mode, with a frequency point of 2.419GHz and LED 3 constantly on.

3. Press the "swing" button for the third time to switch to mode 4: fixed frequency reception mode, with a frequency point of 2.474GHz and LED 4 constantly on.

4. Press the "swing" button for the fourth time to switch to mode 5: fixed frequency reception mode, with a frequency point of 2.445GHz and LED 5 constantly on.

5. Press the "swing" button for the fifth time to switch to mode 6: fixed frequency reception mode, frequency point 2.419GHz, LED4, LED5

Highlight the prompt.

6. Press the "swing" button for the 6th time to switch to mode 7: single carrier mode, frequency 2.474GHz, LED3, LED4, LED5

Always on prompt.

7. Press the "swing" button for the 7th time to switch to mode 8: single carrier mode, frequency 2.445GHz, LED2, LED3, LED4,

LED 5 is constantly on to prompt.

8. Press the "swing" button for the 8th time to switch to mode 9: single carrier mode, frequency 2.419GHz, LED1, LED2, LED3,

LED 4 and LED 5 are constantly on for prompt.

9. Press the "swing" button for the 9th time to return to mode 1: fixed frequency transmission mode, with a frequency point of 2.474GHz and LED1 constantly on.

10. Press for the 10th time and return to mode 2, repeating the cycle.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.