

## Safety Instructions

Read and follow all the safety instructions:

- The bulb is not waterproof. Avoid exposing it to splashing or dripping water.
- The operating temperature should be within -10° to 40°C (14° to 104°F).
- The bulb's internal light source is unfixable. If it breaks, you must replace the entire bulb.
- Do not allow children to install the bulb alone.
- Do not install the bulb with a dimming driver.
- Avoid installing the bulb near heat sources.
- Avoid installing the bulb near potentially dangerous sources (e.g. Candles, liquid-filled objects).


## Introduction

Thanks for choosing the Matter Smart LED Bulb. The LED bulb connects to your smartphone in just a few simple steps. Create the warm, vibrant atmosphere you need at the touch of a button.

## Specifications

Working Voltage	AC 220-240V
Power	9W
Lumen	800lm
Colour Temperature	2700K~6500K
Working Temperature	-10° C to 40° C/14° F to 104° F
Colour	RGBCW

## At a Glance



## Installing Your Bulb


Screw the bulb into base. Notice: Switch off the power switch controlling the bulb before installing



## Pairing Your Bulb with the uHome+ App

What You Need:

- An Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands, 5GHz is not supported.
- A smartphone or tablet running iOS 8.0 (or above) or Android 4.3 (or above).



Download the uHome+ app from the App Store (ios devices) or Google Play (Android devices).

- ① Open the app, tap "+" icon in the top right corner and search "Smart light".
- ② Tap the device icon and follow the on-screen instructions to complete pairing.

## Controlling the Bulb with Your Voice

- ③ Open the uHome+ app, then tap the device icon to enter the details page.

- ④ Tap the "setting" icon **in the top right corner**.
- ⑤ Select "Using Guidance" and follow the on-screen instructions to begin using voice control.

## Troubleshooting

- 01 Cannot connect the bulb to uHome+.
  - Check whether the bulb is powered on.
  - Check whether your smartphone Wi-Fi is enabled. Please make sure Wi-Fi is connected to your phone's 2.4GHz (5GHz band is not supported).
  - Make sure your smartphone is close to the bulb when connecting for the first time.
  - Check if you have entered the correct Wi-Fi password during Wi-Fi setup.
  - Make sure the distance between the bulb and router is less than 15 metres.
  - Check whether the home network is stable by connecting the bulb to another phone's hotspot.

- 02 The bulb lost connection.
  - Check whether the device is powered on.
  - Check whether your home network is stable.
  - Check if there are too many devices connected to the router by connecting the bulb to another phone's hotspot.



#### uHome+ App

For more common FAQs and information  
,please contact via Email:

[partphoner.service@gmail.com](mailto:partphoner.service@gmail.com)

- Ensure the distance between the smartphone and the device does not exceed 15 metres.
- Delete bulbs connected in "My Devices" and reconnect the bulb to Wi-Fi following on-screen instructions

Q How do I create a new scene on the uHome+ app?

- Go to "My Devices" and select "Scene".
- Tap the "+" icon at the top right corner to create a new scene.

**Note: Select different classes based on your needs,**

Q Can I use group control with voice assistance?

- Please make sure your device is connected to Wi-Fi before using voice assistance.
- Please set voice group control in Alexa/Google Assistant App,

## Customer Service

**Warranty:** 12-Month Limited Warranty

**Support:** Lifetime Technical Support

**Email:** [partphoner.service@gmail.com](mailto:partphoner.service@gmail.com)

### Australian Consumer Law

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

	Wi-Fi
Frequency	2.4GHz
Maximum Power	<20dBm

## Matter smart bulb

# User Manual

INSTALLATION OR ASSEMBLY  
THIS DEVICE IS NOT INTENDED FOR USE WITH  
EMERGENCY EXITS

Only use the control provided with or specified by  
these instructions to control this lamp.  
This lamp will not operate properly when connected to  
a standard (incandescent) dimmer or dimming control.



Model:OS010

WiFi+Bluetooth RGBCW LED Bulb

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.