



True Wireless Bluetooth Headset
Instruction manual

Packing list



Product diagram



Tips

1. Except for the operation methods specifically marked in the manual, please do not try to disassemble or replace any parts in the earbuds.
2. Don't put the earbuds in the water or any others liquid. The earbuds are not waterproof.
3. If any liquid enters the product by accidentally, please disconnect and remove the connection immediately.
4. Please make sure that there is no water on your hands when installing or uninstalling the product to avoid electric shock.
5. Do not put the product near by the heat source or expose it to the fire source directly.
6. Do not put the product in the environment with strong electromagnetic force, otherwise it will cause product malfunction.

Product specifications

Bluetooth version: V5.3
Music time: 5hours(60% volume)
Charging time: ≈1.5hours
Rated input: 5V 30mA

Transmission distance: 10M
Horn size: φ13mm
Battery capacity: 35mAh/3.7V

Charging case specifications

Battery capacity: 300mAh/3.7V
Rated input: 5V 250mA
(All technical information is subject to actual performance)
(tip: When the headset is in low power (3.2V-0.1V), there will be a "Please charge" prompt tone every minute until the headset is powered off)



Rated input: 5V 30mA (headset) Rated input: 5V 250mA (charging case)

LED Indicator Status

Power On	Flash the white light
Power Off	Flash the light twice
Successful pairing	The main headphone light is blinking, and the secondary headphone light is off
Successful connection	Headphone light goes out
Empty pair	The light flashed twice and then went out

LED Indicator Status

Earphone charging	After the headphone is in the warehouse, the headphone lamp will turn on and start charging. The charging bay indicator lights on for 5 seconds and then turns off. After the headset is fully charged, the headset indicator is off.
Charging bin	Charging bay indicator flashing, full of steady on

Product Operation Instructions

- ①Turn on
Method 1: Take out the earphone from the charging bin, and the earphone will start automatically
Method 2: The earphone is outside the charging bay and in the off state. Long press the touch position for 5 seconds, and the earphone will have a "power on" prompt tone at the same time
- ②Turn off
Method 1: In the startup state, put the earphone into the charging box, and the earphone will automatically shut down and enter the charging mode
Method 2: Hold down the touch button for 5 seconds, and the earphone will hear the "Power Off" tone
Method 3: When the earphone battery runs out, the earphone has a "power off" prompt tone, and the earphone shuts down itself
Method 4: If no operation is performed after connection or connection is successful, the headset automatically shuts down 5 minutes after timeout
- ③Pairing and connection
Enter the pairing state: After the device is powered on, the left and right earphones are close to each other, and the left and right earphones are automatically connected. When the connection is successful, the earphones will sound "Didi". Earphone connection: After the two earphones are paired, search "STNK-MQM-003" on the mobile phone and click "Connect" to use the earphone. When the connection is successful, the earphone will sound "connection success".



Touch operation

General mode

- Volume Plus: Hit the left Touch three times
Volume reduction: Strike three on the right Touch

Music playback mode

- Play/Pause: Click any Touch key
Previous: Double click on the left Touch button
Next: Double click on the right Touch button

Call mode

- Answer an incoming call: Short press any Touch key to answer an incoming call
Hang up: During a call, press any Touch key to end the call
Reject a call: Hold down the Touch button for 1 second for an incoming call

The name and content of harmful substances in the earbuds

Part Names	Harmful Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.
OIndicates that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572.
XIndicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572.
The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances.

Printed circuit board components:
Including printed circuit boards and their parts, electronic components, etc. and depending on the product model, the earbuds you purchased may not contain all the above components.

Electronic and electrical products sold in the People's Republic of China must mark this LOGO, the number in the logo represents the product under normal use Environmental protection use period.

Certificate of Approval
Product No: _____
Production Time: _____
QC: _____

Warranty statement

Disclaimer
This user manual does not have any form of guarantee, position expression or other implication. The mentioned products, specifications and information are for reference only, and the content will also be updated on the web at any time without additional separate notice.

Warranty statement
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired. Free repair/free replacement if the manufacturer confirms that it cannot be repaired; repaired or replaced product. Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchased by sale the ticket date shall prevail. If the purchase date cannot be determined, the warranty period shall be 15 (15) months.

If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1.Exceeding the validity period of the three packs;
2.Alter the warranty card and product code does not match the product body;
3.Causes caused by misuse, abuse or improper transportation, use, maintenance or storage obstacles or damage;
4.Failure or damage caused by force majeure (such as earthquake, war, disaster, etc.) or accident bad;
5.The zipper and tower buckle are damaged due to excessive force;
6.Disconnection or tearing caused by excessive load;
7.Any damage caused by sharp objects;
8.Products with signs of burning of flooding;
9.Damage caused by unauthorized disassembly;
10.Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product.
11.If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.