

# USER Manual

**Model name:WP2269**

Thank you for purchasing the Presenter. For optimum performance and safety of using this product, please read these instructions carefully before operating the product. Please keep this manual for future reference.

**Packing contents**

- User manual
- Presenter
- USB-C charging cable
- USB-A and USB-C receiver

## Product specifications

Battery:	Lithium-Polymer
Battery capacity:	250 mAh
Input:	5V/1A
Interface:	USB-C 3.0 / 2.0 / 1.1
RF Frequency:	2.4Ghz
Laser:	Class II
Laser power:	Less than 1mW
Laser range:	>50m
Control range:	20m
Laser wave:	650nm, with red pointer
Charging time:	30 minutes
Stand by battery:	100 hours

## Product overview



1. Page up / long click full screen
2. Page down / Long click black screen
3. Laser pointer
4. Power ON/OFF
5. Type-c charging port
6. Receiver USB-A
7. Receiver USB-C

## **Product features:**

### **Red Laser Pointer**

- Red laser for highlighting key points.
- Visible in various lighting conditions.

### **Wireless Connectivity**

- 2.4 GHz wireless connection for seamless performance.
- Reliable range up to [10 meters] for mobility during presentations.

### **Controls**

- Easy-to-use buttons for slide navigation (forward, backward).
- Additional buttons for screen blackout and presentation start/stop.

### **Plug-and-Play Functionality**

- No software installation required.
- USB-A and USB-C receiver for quick setup and immediate use.

### **Energy Efficiency**

- Auto-sleep mode when not in use to preserve battery life.

## **Product usage**

1. Flip the switch from off to on to activate the presenter
2. Flip the switch from on to off to de-activate the presenter

## **Led indication status**

1. When charging, the led indicator will turn red. When the presenter is fully charged, the light will turn off.
2. When you turn the presenter on, the green light will flash once.
3. The red light will flash when the battery is low.

## **How to charge?**

- Use the original charging cable to charge the presenter.
- You can charge the presenter by using a USB-C charging cable combined with a wall charger to a power source.
- Charging time will take around 30 minutes

## **Safety warnings:**

- Only use the provided charging cable to recharge the device.
- Never point the laser at people, animals, or reflective surfaces.
- Avoid direct eye exposure to the laser beam, as it can cause permanent eye damage.
- Clean the device with a soft, dry cloth. Avoid using harsh chemicals or abrasives.

- Keep the device out of reach of children to prevent accidental activation of the laser.
- This device is not a toy and should only be used by responsible individuals.
- Do not store the device in a hot or humid environment.
- Do not place open flames, such as burning candles, on or near the device.
- The device cannot be exposed to water or other liquids. Please avoid placing the device near to a liquid-containing object or water.
- Do not dismantle
- Do not burn

### **FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.