

# AL03GB

## STEP 1

Install AlterLock app and register an account.

Installez l'application AlterLock et créez un compte.

AlterLock アプリをインストールしてアカウントを登録します。

## STEP 2

Register your bike information in the app.

Enregistrez les informations relatives à votre vélo dans l'application.

アプリにバイク情報を登録します。

## STEP 3

Connect AlterLock device.

Connecter le dispositif AlterLock.

AlterLock デバイスを接続します。

## STEP 4

Mount AlterLock device on your bike.

Montez le dispositif AlterLock sur votre vélo.


AlterLock デバイスをバイクに取り付けます。

## Factory Reset / Reset d'usine / リセット方法

Place the device face down on a flat surface and press the button for 5 seconds, then flip it face up and press for 5 seconds.

Placez le dispositif face vers le bas sur une surface plane et appuyez sur le bouton pendant 5 secondes, puis retournez-le face vers le haut et appuyez pendant 5 secondes.

デバイスを裏向きにして水平面に置き 5 秒間ボタンを押してください。更にデバイスを表向きにして 5 秒間ボタンを押してください。



Please install the device on the bottle cage mounts.  
Fixez l'appareil sur les supports de cage à bouteilles.  
デバイスをボトルケージ台座に取り付けます。

Package contents : AlterLock device, 2 security bolts and a installation wrench. \*Please prepare USB Type-C cable for charging separately.

Contenu de l'emballage : Dispositif AlterLock, 2 boulons de sécurité et une clé d'installation. \*Veuillez préparer le câble USB Type-C pour la charge séparément.

同梱品 : オルターロック本体, 盗難防止ネジ, 取付工具  
※充電用の USB Type-C ケーブルを別途ご用意ください。

IMPORTANT : LTE-M communications require a subscription fee. For more information, please visit our product website.

IMPORTANT : Les communications LTE-M nécessitent un abonnement payant. Pour plus d'informations, veuillez consulter notre site web de produits.

重要 : LTE-M 通信を使用するには有料サービス契約が必要です。詳しくは製品の Web サイトをご確認ください。

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Innovation, Science, and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

*Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.*

*L'exploitation est autorisée aux deux conditions suivantes :*

- (1) l'appareil ne doit pas produire de brouillage, et*
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

L'appareil est conforme aux limites d'exposition aux rayonnements spécifiées par la FCC/ISED pour les environnements non contrôlés. La distance entre le radiateur et le corps doit être d'au moins 20 cm lors de l'installation et du fonctionnement de l'appareil.

Cet émetteur ne doit pas coexister ou fonctionner conjointement avec toute autre antenne ou émetteur.