


R12
Open Wearable Stereo

1
Headset connection

First Connection
Turn on bluetooth
Open the earphone box and approach the unlocked mobilephone Search, for bluetooth device and click on the link


Second Connection
Open the headphone box and the headphones will automatically connect to the phone

2
Function




1. In this direction, the battery can be unplugged and replaced
2. Swipe in this direction on the face cover, and you can hear two "click" clicks to increase the volume
3. Slide in this direction on the face cover, and hear two "click" clicks to reduce the volume

3
Multipoint connection



Enable multipoint connection: After the first device is connected, turn off the Bluetooth function of the first device, and the second device can search for connection.
After connecting the second device, turn on the Bluetooth function of the first device, and the earbuds will automatically reconnect with the first device.

4
Factory Reset



Left ear touch point: 1. Touching either side of the left and right earbuds 6 times in a row will erase all pairing history of Bluetooth and complete the factory reset.
2. Touch the right ear twice to enter the Bluetooth pairing mode, and the Bluetooth can be searched for connection.

Right ear touch point: 1. Touching either side of the left and right earbuds 6 times in a row will erase all pairing history of Bluetooth and complete the factory reset.
2. Touch the right ear twice to enter pairing mode and reconnect the device.

Note: Do not use one ear to operate this function. If you touch this function by mistake, please restore the other earphone to factory settings as well. Then touch the right earbud twice to enter pairing mode and reconnect the device.

5
Headset function operation

Function	Use in both ears	Use in one ear
Power play	Touch any earbud once	Touch it
Pause/answer	Touch any earbud twice	Touch and hold any earbud for 2 seconds
Voice assistant	Touch any earbud for 3 seconds	Touch and hold any earbud for 5 seconds
Previous song	Double-touch any earphone	Touch twice
Next song	Touch any earphone three times	Touch three times
Volume up	Slide up on the left/right ear	Slide up on the earphone touch area
Volume down	Slide down on the left/right ear	Slide down on the earphone touch area
Factory reset	Touch any earphone six times	Touch six times
Answer the call	Touch any earbud once	Touch it
Hang up	Double-touch any earphone	Touch twice
Reject a call	Double-touch any earphone	Touch twice
Manual shutdown	Touch any earphone for 10 seconds	Touch and hold the earbuds for 10 seconds
Manual shutdown	Touch and hold any earphone for 10 seconds	Touch and hold the earbuds for 10 seconds

6
The headphones are lit up

Mode	White light	Green light	Remark
charge	Solid on	Not lit	
Fully charged	Not lit	Not lit	
Power on and off	The white and green lights flash alternately		
Power on and off	Left earbud earphone	Not lit	
Power on and off	Right earbud earphone	Not lit	
Power on and off	Both earbuds earphones	Not lit	
When a call comes in	Solid on	Not lit	
On a call	Flashes 3 times in 5 seconds	Not lit	
Low power	Flashes 3 times every 1 minute		
bootable	Not lit	Bright for 2 seconds	
Shutdown	Bright for 2 seconds	Not lit	
Factory reset	Not lit	Bright for 2 seconds	
warning	Not lit	Flash slowly once	

7
The charging compartment is lit up

Mode	White light	green light	Orange light
charge	Not lit	Not lit	Solid on
Fully charged	Not lit	Not lit	Not lit
Headphones are connected	Not lit	Take 1 breath	Not lit
The headphones are out of the charging compartment	Not lit	Not lit	Not lit
Charge the earbuds and the earbuds are out of the charging compartment	Not lit	Solid on	Not lit
Charge the earbuds and the earbuds are in the charging compartment	Breathe 3 times	Not lit	Not lit
Sleep	Take 1 breath	Not lit	Not lit
Sleep	Not lit	Not lit	Not lit
When the earbuds are out of the charging compartment	Not lit	Not lit	Not lit
Low power	Not lit	Breathe 4 times	Not lit
Low power	Not lit	Not lit	Not lit
Low power	Not lit	Breathe 2 times	Not lit
Low power	Not lit	Take 1 breath	Not lit
Low power	Not lit	Not lit	Take 1 breath

8
Description of the feature definition

Power on: The charging compartment is automatically turned on and automatically paired after opening the cover.
Shutdown: Put into the charging compartment and close the cover, the headphones will automatically disconnect from the phone.
Single ear use: Turn on the charging compartment to start automatic pairing, connect Bluetooth successfully, take out the single ear, cover the charging compartment to use the single ear function.
Automatic back connection: the headset pair name is not deleted when the phone is connected, and the cover can be automatically connected back

9
Basic functions of the charging case

TWS automatic matching: the earphone is put into the charging compartment, open the upper cover of the charging compartment, and pair the ear successfully.

Headphone version: 5.4
Transmission frequency: 2.4GHz-2.4835GHz (ISM Band)
Max. sensitivity: -123dBm
Support Protocols: AVRCP/A2DP/HSP/HFP

10
Precautions for use

The earphones should be stored in a dry and ventilated environment, to avoid oil, water, moisture and dust affecting product performance.
Shutdown: Put into the charging compartment and close the cover, the headphones will automatically disconnect from the phone.
Avoid using stimulants, organic solvents or items containing these ingredients to clean the earphones.
The use of earphones should be correctly as per the specification, pay attention to use the influence of environment on the earphones.
In order to ensure the smooth connection, it is recommended that the distance between the earphones and phones with in 15 meters.
If the earphones failed to connect or with poor connection, pls do not take apart the earphones or the accessories on your own. Otherwise, no warranty.

Regarding charging earphones, pls use the standard us cable orported charging cable from our company to charge the earphones

11
Warn

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If the equipment does exceed the limits, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

12
Warranty Card

1. If the product has any functional problems, you can enjoy the warranty service. (The warranty period is 2 years.)
2. Man-made damage, broken, artificially scratched, no warranty card is not covered by the warranty.
3. Customers must submit all necessary information (customer name, address, phone number, date of purchase, etc.)
4. Warranty service requires a warranty card and can be operated as required, otherwise no warranty.

Product model: _____
Customer's name: _____
Contact number: _____
Customer's address: _____
Date of purchase: _____