

70x100mm 80G铜版纸单黑印刷







三.Bluetooth usage

Power on: Press and hold the "O" button for 2 seconds
When the speaker is turned off, press and hold the "O" button for 2 seconds,
and a power on prompt will automatically enter pairing search mode.
At this time, the speaker can be detected by other devices

Shutdown: Press and hold the "U" button for 3 seconds When the speaker is turned on, press and hold the "(1)" button for 3 seconds, and there will be a prompt sound

2.Bluetooth control



— : Vol **ு** : Power button

+ : Volume increase * : Light key

Click the "O" button to answer; Long press"O" for 1 second to reject/double-click"O" to call back

3.TWS Interconnected Surround Sound Effects

After the two speakers are turned on and there is no connection (if there is a connection to a phone or device, it is necessary to disconnect it before operating), press the "O" button three times, and the speakers will emit a beep to start TWS interconnection pairing. After waiting for a few seconds, the TWS interconnection pairing of the two speakers is successful, accompanied by a beep sound. After the successful pairing of the speaker TWS, use your phone or device to search for "X3" pairing to connect to the speaker and achieve surround sound playback of music. To release TWS interconnection pairing, press the "O" button three times again in interconnection mode to release it, accompanied by a release prompt sound. After removal,

4. Light effect control

Press the *k key to turn on or off the light effect.

Long press the *k button: infinitely adjust the brightness of the light effect, select the appropriate brightness, and then release the button. Brightness memory function: Automatically adjust the brightness of the light effects to the previously memorized brightness when the light effects are turned off the next time.

5.Charging control

Charging: The orange light stays on for a long time.
Fully charged: The orange light goes out.
"When not in use for a long time, it is recommended to replenish
the battery every 3 months to avoid battery depletion, which may result in
reduced battery life or battery damage.

matters needing attention

A. Do not use abrasive cleaning agents to clean this product

B. Do not allow this product to be heated or placed near a source of fire, such as a cooking stove

C. Do not expose this product to direct sunlight for an extended period of time. D. Do not dispose of this product in fire to avoid explosion.

E. Do not use this product in the rain.

F. Do not attempt to disassemble this product for any modifications, as it does not contain

G. If you do not intend to use this product for a long time, please store it in a dry environment to avoid extreme temperatures and dust!

((Made in China

To assure continued compliance, any changes or modifications not expressly approved by the party.Responsible for compliance could void the user's authority to operate this equipment.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class, B digital device, pursuant to part 15 of the ECC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no quarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement: The device has been evaluated to meet general RF exposure

requirement. The device can be used in the portable exposure condition without