

WIRELESS MONITORING MODULE FOR HYDRA ELECTRONIC SUCTION CUP

DISCLAIMER

Thank you for purchasing TILTA products. Before using this product, please carefully read this document to ensure that the product has been set up correctly. The final interpretation of this document and all related documents for this product belongs to TILTA. For updates, please visit the official website at www.tilta.com for the latest product information. TILTA reserves the right to modify any information in this manual at any time without prior notice and without assuming any responsibility.


By using this product, you are deemed to have carefully read the disclaimer and warnings, understood, agreed, and accepted all the terms and content of this statement. You promise to take full responsibility for the use of this product and any consequences that may arise. You commit to using this product only for legitimate purposes and agree to these terms as well as any related regulations, policies, and guidelines set by TILTA.

TILTA is not responsible for any damages, injuries, or legal liabilities caused directly or indirectly by the use of this product. Users should follow all safety guidelines mentioned in this document, including but not limited to those mentioned.

Despite the above provisions, consumer rights are still protected by local laws and regulations and are not affected by this disclaimer.

TILTA is a trademark of Shenzhen TILTA Technology Co., Ltd. and its affiliated companies. Product names, brands, and other trademarks appearing in this document are trademarks or registered trademarks of their respective companies.

OVERVIEW



Antenna
Display
Up Button
Menu/Back
Down Button
1/4-20 Thread
USB-C Port
Confirm/Deflate
SUCTION
BATTERY INFO

SPECIFICATIONS

- Net Weight: 38 g / 1.34 oz
- SKU: HDA-ESC-WMM
- DIMENSIONS: 42.2x22.8x74 mm / 1.66x0.9x2.91 in


PACKING LIST



Wireless Monitoring Module for Hydra Electronic Suction Cup x1
USB-A to USB-C Power Cable x1
User Guide x1
HYDRA ARM


HOW TO

INITIATE DEFLECTION



USB-C to USB-C or USB-A to USB-C
EXTERNAL BATTERY
User Guide x1
HYDRA ARM

OVERVIEW



Antenna
Display
Up Button
Menu/Back
Down Button
1/4-20 Thread
USB-C Port
Confirm/Deflate
SUCTION
BATTERY INFO

INITIATE DEFLECTION


Single Click: The [UP]/[DOWN] button to select the suction strength. Single Click: The [ENTER] button to enter the deflation status. Click and Hold: When not on the [HOME] page, single click to return to the previous page. (3) On the deflation page, single click to exit the deflation status.

RELEASE FUNCTION



ALARM
RELEASE FUNCTION
SEARCH
[RELEASE FUNCTION] DEVICE

HOME PAGE




CONT
TRAY
[HOME] PAGE
[RELEASE FUNCTION] DEVICE

DEFLECTION



DEFLECTION
[DEFLECTION] DEVICE

ALERT PROMPT (RED & YELLOW FLASHES)



IGNORE
REMINDER IN 1 MIN
[ENTER] DEVICE

03 BUTTON FUNCTIONS AND INSTRUCTIONS

POWER ON



POWER ON
[POWER ON] DEVICE

ALERT PROMPT

IGNORE
REMINDER IN 1 MIN
[ENTER] DEVICE

04 MENU SETTING

INITIATE DEFLECTION

INITIATE DEFLECTION
[ENTER] DEVICE

PRODUCT NAME

PRODUCT NAME
[ENTER] DEVICE

PRODUCT MODEL

PRODUCT MODEL
[ENTER] DEVICE

05 WARRANTY

WARRANTY

This equipment has been tested and found to comply with the limits established by ICES-003, RSS-247 and IC:003. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular situations. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Use an shielded power cord or circuit to prevent damage to the equipment and receiver.
- Consult the supplier or an experienced technician for help.

Once the anomaly is resolved, the system will automatically return to the [HOME] page, and the vibration (can be disabled) and buzzer alarm (can be disabled) will stop.

REPAIR AND MAINTENANCE

1. The mechanical and electronic components of this product are covered by a one-year warranty (excluding damage caused by user errors).

2. An alarm will sound when the device is not connected to power or if the power source is interrupted. If the device is on the [HOME] page, long-pressing the [ENTER] button to initiate deflation will not trigger the alarm.

3. A valid warranty card must be presented for warranty service. If the card is not provided, it has been altered without authorization, the company reserves the right to deny warranty service.

4. Unless otherwise controlled by law, the equipment should be returned to the manufacturer for repair or replacement.

ALERT PROMPT (RED & YELLOW FLASHES)

Displays the number of abnormal suction cups.

Single click the [ENTER] button to ignore the alert. The alert will not trigger again unless the device is restarted.

06 FIRMWARE UPDATE

INITIATE DEFLECTION

INITIATE DEFLECTION
[ENTER] DEVICE

PRODUCT NAME

PRODUCT NAME
[ENTER] DEVICE

PRODUCT MODEL

PRODUCT MODEL
[ENTER] DEVICE

07 C Statement

WARRANTY

This equipment has been tested and found to comply with the limits established by ICES-003, RSS-247 and IC:003. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular situations. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Use an shielded power cord or circuit to prevent damage to the equipment and receiver.
- Consult the supplier or an experienced technician for help.

Once the anomaly is resolved, the system will automatically return to the [HOME] page, and the vibration (can be disabled) and buzzer alarm (can be disabled) will stop.

REPAIR AND MAINTENANCE

1. The mechanical and electronic components of this product are covered by a one-year warranty (excluding damage caused by user errors).

2. An alarm will sound when the device is not connected to power or if the power source is interrupted. If the device is on the [HOME] page, long-pressing the [ENTER] button to initiate deflation will not trigger the alarm.

3. A valid warranty card must be presented for warranty service. If the card is not provided, it has been altered without authorization, the company reserves the right to deny warranty service.

4. Unless otherwise controlled by law, the equipment should be returned to the manufacturer for repair or replacement.

ALERT PROMPT (RED & YELLOW FLASHES)

Displays the number of abnormal suction cups.

Single click the [ENTER] button to ignore the alert. The alert will not trigger again unless the device is restarted.

08 F Statement

WARRANTY

This equipment has been tested and found to comply with the limits established by ICES-003, RSS-247 and IC:003. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular situations. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Use an shielded power cord or circuit to prevent damage to the equipment and receiver.
- Consult the supplier or an experienced technician for help.

Once the anomaly is resolved, the system will automatically return to the [HOME] page, and the vibration (can be disabled) and buzzer alarm (can be disabled) will stop.

REPAIR AND MAINTENANCE

1. The mechanical and electronic components of this product are covered by a one-year warranty (excluding damage caused by user errors).

2. An alarm will sound when the device is not connected to power or if the power source is interrupted. If the device is on the [HOME] page, long-pressing the [ENTER] button to initiate deflation will not trigger the alarm.

3. A valid warranty card must be presented for warranty service. If the card is not provided, it has been altered without authorization, the company reserves the right to deny warranty service.

4. Unless otherwise controlled by law, the equipment should be returned to the manufacturer for repair or replacement.

ALERT PROMPT (RED & YELLOW FLASHES)

Displays the number of abnormal suction cups.

Single click the [ENTER] button to ignore the alert. The alert will not trigger again unless the device is restarted.