

Owner's Manual

AW-BT01

Safety Instructions


- Please read this manual carefully before using
- Keep these instructions
- Do not disassemble
- Do not expose directly to sunlight or open flame
- Pay attention to the road and do not operate this product while driving

Introduction

Features:


- Input 12-24V
- Bluetooth hands-free calling
- USB-A: 5V/2.4A
- USB-C: PD 30W 5V/3A, 9V/3A, 12V/2.5A
- Support USB flash drive playing
- Auxiliary (AUX) output to car auxiliary (AUX) port
- The sound filtering function helps to reduce the level of extraneous noises during a telephone conversation

Button and port distribution:



Get it Ready for Playing

1. Insert the device into the car cigarette lighter
2. Insert the Auxiliary plug (AUX) into the car's auxiliary (AUX) port



3. Open the Bluetooth app on your phone, turn on the Bluetooth function, search for available devices, and connect to the Bluetooth receiver named "AW-BT01"



4. After connecting with your phone via Bluetooth, you can play music from your phone through your car's audio system

Previous Track / Volume -	Press / Press and hold ⏪
Previous Track / Volume +	Press / Press and hold ⏩
Play/Pause	Press ⏴
Switch play mode	Press and hold ⏴

Hands-Free Call

After you set up playing, you can also use the hands-free function

Answer the incoming call	Press ⏴
Reject an incoming call	Press and hold ⏴
Hang up a call	Press ⏴
Repeat Last Incoming/ Outgoing Call	Quickly press twice ⏴

Under music playing status, if there is a call coming in, it will switch to call mode automatically. After hanging up, it will switch back to playing mode automatically.

Charge Your Device

Two USB ports provide a total power of 42W to 2 devices at the same time (USB-A: 5V/2.4 A, max. 12W +USB-C, max. 30 W)

Specifications

- DC power consumption (constant current): 12V-24V
- Power output: USB-A: 5V/2.4A
USB-C: PD30W
- Effective Bluetooth distance: < 8m
- Bluetooth protocol: AVRCP, HFP, A2DP
- Audio format: MP3, WMA
- USB capacity support: ≤ 64GB
- Working temperature range: -20°C to 40°C
- Storage temperature range: -40°C to 75°C

Note: The manufacturer reserves the right to make changes to the design and/or specifications of the device without prior notice.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To maintain compliance with FCC'S RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm between the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.