



5. Spurious Emissions

Condition	Antenna	Modulation	TX Mode	Spurious MAX.Value(dBm)	Limit	Result
NVNT	ANT1	1-DH1	2402.00	-37.874	-23.525	Pass
NVNT	ANT1	1-DH1	2441.00	-37.907	-23.708	Pass
NVNT	ANT1	1-DH1	2480.00	-38.478	-24.301	Pass
NVNT	ANT1	2-DH1	2402.00	-37.377	-23.565	Pass
NVNT	ANT1	2-DH1	2441.00	-37.625	-23.726	Pass
HVNT	ANT1	2-DH1	2480.00	-37.678	-24.265	Pass
HVNT	ANT1	3-DH1	2402.00	-37.175	-23.366	Pass
HVNT	ANT1	3-DH1	2441.00	-41.604	-23.578	Pass
HVNT	ANT1	3-DH1	2480.00	-38.885	-24.186	Pass


1 Reference Level NVNT ANT1 1-DH1 2402 00




2 Spurious Emissions NVNT ANT1 1-DH1 2402 00




1 Reference Level NVNT ANT1 1-DH1 2441 00




2 Spurious Emissions_NVNT_ANT1_1-DH1_2441_00




1 Reference Level_NVNT_ANT1_1-DH1_2480_00




2 Spurious Emissions_NVNT_ANT1_1-DH1_2480_00




1 Reference Level_NVNT_ANT1_2-DH1_2402_00




2 Spurious Emissions_NVNT_ANT1_2-DH1_2402_00



1 Reference Level_NVNT_ANT1_2-DH1_2441_00




2 Spurious Emissions_NVNT_ANT1_2-DH1_2441_00




1 Reference Level_HVNT_ANT1_2-DH1_2480_00




2 Spurious Emissions HVNT_ANT1_2-DH1_2480_00




1 Reference Level HVNT_ANT1_3-DH1_2402_00




2 Spurious Emissions HVNT_ANT1_3-DH1_2402_00



1 Reference Level HVNT_ANT1_3-DH1_2441_00




2 Spurious Emissions HVNT_ANT1_3-DH1_2441_00



1 Reference Level HVNT_ANT1_3-DH1_2480_00





2_Spurious_Emissions_HVNT_ANT1_3-DH1_2480_00




6. Bandedge

Condition	Antenna	Modulation	TX Mode	Bandedge MAX.Value	Limit	Result
NVNT	ANT1	1-DH1	2402.00	-45.666	-23.525	Pass
NVNT	ANT1	1-DH1	Hopping_LCH	-45.949	-22.930	Pass
NVNT	ANT1	1-DH1	2480.00	-53.650	-24.301	Pass
NVNT	ANT1	1-DH1	Hopping_HCH	-54.492	-23.324	Pass
NVNT	ANT1	2-DH1	2402.00	-45.723	-23.565	Pass
NVNT	ANT1	2-DH1	Hopping_LCH	-45.576	-23.164	Pass
HVNT	ANT1	2-DH1	2480.00	-53.348	-24.265	Pass
HVNT	ANT1	2-DH1	Hopping_HCH	-53.333	-23.217	Pass
HVNT	ANT1	3-DH1	2402.00	-45.676	-23.366	Pass
HVNT	ANT1	3-DH1	Hopping_LCH	-47.219	-22.710	Pass
HVNT	ANT1	3-DH1	2480.00	-53.705	-24.186	Pass
HVNT	ANT1	3-DH1	Hopping_HCH	-53.764	-23.015	Pass







1 Reference_Level_Hopping_NVNT_ANT1_1-DH1_Hopping




2 Band Edge_(Hopping)_NVNT_ANT1_1-DH1_Hopping




1 Reference Level NVNT ANT1 1-DH1 2480 00




2 Bandedge NVNT ANT1 1-DH1 2480 00



1 Reference_Level_Hopping_NVNT_ANT1_1-DH1_Hopping




2 Band Edge_(Hopping)_NVNT_ANT1_1-DH1_Hopping




1 Reference Level NVNT ANT1 2-DH1 2402 00




2 Bandedge NVNT ANT1 2-DH1 2402 00




1 Reference_Level_Hopping_NVNT_ANT1_2-DH1_Hopping




2 Band Edge (Hopping)_NVNT_ANT1_2-DH1_Hopping




1 Reference Level HVNT ANT1 2-DH1 2480 00



2 Bandedge HVNT ANT1 2-DH1 2480 00




1 Reference_Level_Hopping_HVNT_ANT1_2-DH1_Hopping




2 Band Edge (Hopping) HVNT ANT1_2-DH1_Hopping




1 Reference Level HVNT ANT1 3-DH1 2402 00




2 Bandedge HVNT ANT1 3-DH1 2402 00



1 Reference_Level_Hopping_HVNT_ANT1_3-DH1_Hopping




2 Band Edge (Hopping) HVNT ANT1_3-DH1_Hopping




1 Reference Level HVNT ANT1 3-DH1 2480 00



2 Bandedge HVNT ANT1 3-DH1 2480 00



1 Reference_Level_Hopping_HVNT_ANT1_3-DH1_Hopping



2 Band Edge (Hopping) HVNT ANT1 3-DH1 Hopping

