















A11说明书规格: 88×100mm

材质: 128G 铜版纸 风琴折页

<p><b>A11</b></p>  <p><b>CD PLAYER</b> Ver1.0</p> <p>1</p>	<p><b>WHAT'S IN THE BOX?</b></p>  <p>① CD Player ② Type-C charging cable ③ Remote control ④ 3.5mm aux cable ⑤ Instruction manual</p> <p>2</p>	<p><b>PRODUCT SPECIFICATIONS</b></p> <table border="1"><tr><td>Product name</td><td>CD Player</td></tr><tr><td>Input power</td><td>DC 5V/2A</td></tr><tr><td>Bluetooth version</td><td>5.0</td></tr><tr><td>BT protocol support</td><td>ADP/AVRCP</td></tr><tr><td>BT receiving distance</td><td>10M</td></tr><tr><td>Battery capacity</td><td>3.6V/2600mAh</td></tr><tr><td>Output Power</td><td>speaker(4Ω)2X2W;earphone(16Ω)2X20mW</td></tr><tr><td>USB playback format</td><td>MP3/VMA/WAV/APE/FLAC</td></tr><tr><td>CD playback format</td><td>CD-DA/MP3/CD-R</td></tr><tr><td>Audio In</td><td>3.5mm Audio In</td></tr><tr><td>Analog audio output</td><td>3.5mm stereo headphone output</td></tr><tr><td>Charging cable length</td><td>80CM</td></tr><tr><td>Product Size</td><td>210X170X77mm</td></tr><tr><td>Product weight</td><td>about 985g</td></tr><tr><td>Product accessories</td><td>(charging cable, audio cable, manual, remote)×1</td></tr></table> <p>3</p>	Product name	CD Player	Input power	DC 5V/2A	Bluetooth version	5.0	BT protocol support	ADP/AVRCP	BT receiving distance	10M	Battery capacity	3.6V/2600mAh	Output Power	speaker(4Ω)2X2W;earphone(16Ω)2X20mW	USB playback format	MP3/VMA/WAV/APE/FLAC	CD playback format	CD-DA/MP3/CD-R	Audio In	3.5mm Audio In	Analog audio output	3.5mm stereo headphone output	Charging cable length	80CM	Product Size	210X170X77mm	Product weight	about 985g	Product accessories	(charging cable, audio cable, manual, remote)×1	<p><b>BUTTON PANEL CONTROLS</b></p>  <p>① COLORED LANTERN ② LONG PRESS:STANDBY SHORT PRESS:ON/INPUT SOURCE SELECTION(CD,USB,AUX,BT) ③ LONG PRESS:JUMP TO THE PREVIOUS LIGHTING EFFECT SHORT PRESS:PREVIOUS ④ LONG PRESS:JUMP TO THE NEXT LIGHTING EFFECT SHORT PRESS:NEXT ⑤ VOLUME BUTTON ⑥ TONEARM SWITCH(PLAY/PAUSE)</p> <p>4</p>	<p><b>REAR PANEL CONNECTIONS</b></p>  <p>① OPTICAL FIBER OUTPUT ② AUX AUDIO INPUT TERMINAL ③ HEADPHONES OUTPUT TERMINAL ④ USB INPUT TERMINAL ⑤ TYPE-C POWER TERMINAL ⑥ SWITCH</p> <p><b>LED DISPLAY</b></p>  <p>① BLUETOOTH ② USB ③ CD ④ POWER ⑤ SINGLE LOOP ⑥ TRACK NUMBER ⑦ ALL LOOP ⑧ RAND ⑨ PLAYTIME(SECONDS) ⑩ AUX</p> <p>5</p>	<p><b>REMOTE CONTROLLER</b></p>  <p>① STANDBY/ON ② VOLUME+ ③ PREVIOUS ④ VOLUME- ⑤ REPEAT/SHUFFLE ⑥ BASS +/− ⑦ BT TRANSMITTING SIGNAL ⑧ MUTE ⑨ NEXT ⑩ PLAY/PAUSE ⑪ STOP ⑫ INPUT SOURCE SELECTION (BT/AUX/CD/USB) ⑬ TREBLE +/− ⑭ EQ</p>  <p>6</p>
Product name	CD Player																																		
Input power	DC 5V/2A																																		
Bluetooth version	5.0																																		
BT protocol support	ADP/AVRCP																																		
BT receiving distance	10M																																		
Battery capacity	3.6V/2600mAh																																		
Output Power	speaker(4Ω)2X2W;earphone(16Ω)2X20mW																																		
USB playback format	MP3/VMA/WAV/APE/FLAC																																		
CD playback format	CD-DA/MP3/CD-R																																		
Audio In	3.5mm Audio In																																		
Analog audio output	3.5mm stereo headphone output																																		
Charging cable length	80CM																																		
Product Size	210X170X77mm																																		
Product weight	about 985g																																		
Product accessories	(charging cable, audio cable, manual, remote)×1																																		
<p><b>POWER ON/STANDBY</b></p>  <p>① Turn the switch to ON state button ⑥ on the rear panel</p>  <p>② To turn on the unit,click the STANDBY button ② on the button panel ③ To put the unit into standby mode,long press the STANDBY button once again</p> <p>6</p>	<p><b>BLUETOOTH MODE</b></p>  <p>① Select the Bluetooth mode.Click the SOURCE(button②) on the button panel,until the BT option appears on the screen.The light will start flashing,which means the unit is ready to pair</p>  <p>② Search for the pairing name THINKYA CD in the list of Bluetooth devices ③ Stay close.The effective range of Bluetooth devices is 10 meters</p> <p>7</p>	<p><b>USB-MP3</b></p>  <p>① Plug the desired USB in the USB input slot of the rear panel</p>  <p>② Devices compatible with USB 2.0 Size 32Gb ③ Select the USB mode.Using the button panel (SOURCE button②)</p> <p>8</p>	<p><b>PLAYING CDS</b></p>  <p>① Select the CD mode. ② Insert the CD into the tray</p>  <p>③ Click Play(button⑥) on the button panel.You can play your CD-DA,CD-R and CD with files in MP3 format ④ Press the STOP(button⑥) on the button panel to stop playback</p> <p>9</p>	<p><b>THINKYA</b></p> <p>Follow us! Thinkya</p>  <p>10</p>																															

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### RF Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.