




Works with
Apple Find My

Slimcard Bluetooth finder



Thank you for choosing the Slimcard Bluetooth finder. Please read this manual carefully before use to avoid damage caused by improper use.

Quick instructions

1. Turn on the device

Press and hold the button for 3 seconds, and the device will beep and turn on. Double press the button, A chime will sound.

Note:To turn off, double-click the device first, then quickly press the button 5 times within 2 seconds, a long beep will sound.

2. Pair the device

- Open the Find My app.
- Hold the device close to your iPhone, tap the Items tab, tap+and then Add Other Item.
- Tap Connect.
- Type a name for your device, select an emoji.
- Tap Agree to acknowledge that this item will be linked to your Apple ID.
- Tap Finish.

3. Enable Lost Mode

- Open the Find My app, tap the Items tab, then tap your item.
- Under Lost Mode, tap Enable.
- Read the instructions, tap Continue and enter a phone number or email address.
- Confirm the information, customize the lost message, and tap Activate to complete the setup.

4. Remove the device

- Open the Find My app, tap the Items tab, then tap your item.
 - Tap Remove Item and then tap Remove to complete the operation.
- Note:**After removing the device in the app, the device will beep, it will not turn off and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will enter the sleep state, and it is difficult to pair at this time. If you need to pair the device, you need to click the device button twice quick, and then the device will beep, at this point, the device enters the pairing state and can be re-paired with the app.

Main Functions

1. Locate your item

If your missing item isn't nearby, the Find My app can still help you track it down using the Find My network—hundreds of millions of iPhone, iPad, and Mac devices around the world. Nearby devices securely send the location of your missing device to iCloud, then you can see where it is in the Find My app. It's all anonymous and encrypted to protect everyone's privacy.

2. Play Sound

Open the Find My app, tap the Items tab, then tap your item. Click Play Sound, and the device will beep, so you can find the item easily.

1. Power on

Press and hold the button for 3 seconds, the device will be turned on.

2. Device status confirmation

Double-click the device button, the device will beep, indicating that the device is working. If the device does not ring, the device is off. Long press the button for 3 seconds to turn it on.

Note:Two different types of beep might appear depending on the device status.

(1) A light music will sound if the device is unpaired and ready to get paired.

(2) Short 3 beeps will sound if the device is already paired.

3. The device enters the pairing state again

After removing the device in the app, the device will beep, it will not turn off and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will enter the sleep state, and it is difficult to pair at this time. If you need to pair the device, you need to click the device button twice quick, and then the device will beep, at this point, the device enters the pairing state and can be re-paired with the app.

4. Factory Reset

First, remove the item from Find My app then, after the device is powered on, double-click the device button. The device will beep. Long press the device button for five seconds, device beep, continue to press three seconds until the device beeps again. Release the button to complete factory reset. The device can now be paired.

5. Power off

When the device is on, press the device button 5 times in 2 seconds. The device will beep, the device will be powered off.

FAQ

1. When can the device be located?

When an item is separated from its owner for a period of time, it can be found by other Apple devices that are part of the Find My network, and the owner can start to get the location of the device.

2. How to confirm whether the device has been turned on?

Double-click the device button, the device will beep, indicating that the device is working. If the device does not ring, the device is off. Long press the button for 3 seconds to turn it on.

3. How is the device designed to discourage unwanted tracking?

If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:

1. If you have an iPhone, iPad, or iPod touch, Find My will send a notification to your Apple device. This feature is available on iOS or iPad OS 14.5 or later.
2. If you don't have an iOS device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved. These features were created specifically to discourage people from trying to track you without your knowledge.

4. How is my privacy protected?

Only you can see where your item is. Your location data and history are never stored on the item itself. Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way. So not even Apple knows the location of your device or the identity of the device that helps find it.

5. How to charge the device?

Place the device on the wireless charger, adjust the card position till the red light is on, the device will be in a charging state. Please pay attention to the wireless charging indicator on the surface of the device and ensure that the device is placed in the correct way.

6. What is the Find My network? And how does it work?

The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, iPod touch, Mac, or the Find My app.

Items app on Apple Watch. Simply pair your compatible product with the Apple Find My app to view it right along side your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple, can view its location.

Important tips

When pairing a device with Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following actions are recommended:


1. Change the phone's network, such as switching between WiFi and mobile network;
2. Factory Reset for the device: When the device is powered on, double-click the device button. The device will beep. Long press the device button for five seconds, device beep and continue to press three seconds until the device beeps again. Release the button to complete factory reset.

NOTE


Slimcard Bluetooth finder has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, watchOS or macOS is recommended. Apple, Apple Watch, watchOS, iPad, iPadOS, iPod touch, Mac, and macOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and issued under license.

Illustrative example



1. Tap the "Find My" app, tap + to add items, tap or other supported items, enter the search status and find the product.



2. Click "Connect", enter the name of any element, click Continue, select any emoji, and then click Continue to go to the linked page.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.