

MANUAL-A15
MINI WATERPROOF SPEAKER


IP67 Waterproof and dustproof

EASY

WIRELESS SPEAKER A15

MANUAL

CONNECT O BT DEVICE



<Ajuste


Wireless

wireless

Other Devices

FAM EASY

OPERATIONS



1.Power ON/OFF: Press and hold the button 2 seconds for Power and Off

RESET: Press and hold the button 8 seconds for RESET

2.BT,Press the button to connect and disconnect

TWS, Press and hold the button to connect and disconnect

3.EQ: Press the button to switch the EQ mode -Standard/ ECO

4.Volume -P Reset Knob

Next song:Press and hold the button

5.Play&Pause: Press the

6.Volume-: Press the button

Previous song: Press and hold the button

7.Parta Type C to load

8.Led

SPECIFICATIONS

Model No:EASY A15

Speaker: 45mm

BT version: 5.3

Output Power:10W

Frequency Response: 100Hz-20KHz

SNR(Signal-to-Noise Ratio)>85dB

Distance of BT<30m

Battery Charge Time:2.5hours(5V/1A)

Operating temperature: -10°C~ 45°C

Battery Type: 7.4Wh Lithium-ion Polymer (2000mAh/3.7V)

Battery Life: 06H on Standard and 08H on ECO.

(Data was obtained with the volume at 50%. The actual usage time may vary depending on the volume and type of music.)

EQ: Standard/ ECO

IP66


Dual Protection

Dust Sand Waterproof


WATERPROOF

AND DUSTPROOF


COLOR OPTIONS



BLACK



ROSE



BLUE

90*80mm

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.