


User Manual

Model Number: SC-1000



Contents

- 10,000 mAh Power Bank

2. Product Specifications

- 2.1. Rated Capacity: 10,000 mAh at 3.7V*

- 2.2. Input:

- USB-C: PD2.0 20W Fast Charging

- 2.3. Output

- USB-C: PD2.0 20W Fast Charging

- USB-A: QC3.0=18W SCP=22.5W Fast Charging

- USB-A: QC3.0=18W Fast Charging

- Wireless Charging: 5W/7.5W/10W/15W Fast Charging

3. Instructions

- 3.1. Charging the Power Bank

- Connect a charger to a wall outlet and use the USB-C port to charge the device.
- The device will begin to charge automatically. Charge times will vary based on the device used to charge the Power Bank and the capacity of the battery at the time of charging.
- The battery charge level is shown with the LED indicator lights. When the lights are blinking the Power Bank is charging.

- 3.2. Charging your devices

- To charge using a USB port plug the correct cable in the USB port and connect the other end to your device. The Power Bank will start to discharge automatically.
- To use Wireless Charging place the device on the Power Bank aligning the its Wireless Charger with the logo on the Power Bank. Press the Power Button to activate wireless charging.
- The remaining battery charge level is shown with the LED indicator lights. When the lights are blinking the Power Bank is discharging.

- 3.3. Indicator Lights

| Light | Capacity |
|----------------|-------------------------|
| No Lights | 0% |
| 1 White Light | 1% - 25% |
| 2 White Lights | 26% - 50% |
| 3 White Lights | 51% - 75% |
| 4 White Lights | 76% - 100% |
| Green Light | Device is fast charging |

4. Troubleshooting

- 4.1. If a device is removed from the Power Bank while Wireless Charging and then replaced and the device doesn't begin to charge again:

- Remove the device from the charger.
- Hold the Power Button for >3 Seconds.
- Replace device on the Power Bank.
- Press the Power Button. The device should begin to charge again.

5. Safety

- 5.1. Using the incorrect charging equipment may result in a fire or injury.

- 5.2. Do not expose the device to temperatures above 140° F (60° C).

- 5.3. Keep out of reach of children.

- 5.4. If device shows signs of swelling or abnormal shape stop using the device and dispose of it immediately.

*Actual capacity may differ depending on the charging voltage.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to mee general RF exposure requirement. The device can be used in portable exposure condition without restriction.