

2.4GHZ OPERATION INSTRUCTIONS

- Thank you for using our company's toy products. In order to give you a better understanding of this product, please read the following instructions carefully before use. This will bring you a different operating experience.
- This product is suitable for children aged 6 and above. After assembly/charging by adults, children can play with it.

⚠ Warning: Please do not disassemble or modify this product without authorization. Any modifications may cause the product to malfunction.


BATTERY INSTALLATION

1. Turn the switches on the remote control car and remote control to the "OFF" position.
2. Use a Phillips screwdriver to open the battery cover.
3. Insert the battery, as shown in the following figure.
4. Cover the battery cover.

HOW TO PLAY REMOTE CONTROL CARS

1. Turn on the remote control car/remote control switch to complete frequency alignment.
2. Use the buttons on the remote control to control the car's forward or backward movement, as well as left or right turns.
3. When the battery level is depleted and the left and right steering becomes insensitive, Moving forward and backward will also slow down. At this point, the battery needs to be removed for charging.



Rechargeable battery (including)



USB CHARGER

Charging time, 3 hours, play time of 30 minutes


Charging port (using 1X3.7V rechargeable battery)



Using 2X1.5V "AA" battery (not included)


HOW TO USE THE BASIC OPERATION OF THIS PRODUCT

Figure 1




Press the forward button to move the car forward.

Figure 2




Press the back button to move the car forward.

Figure 3




Press the left turn button and the car will turn left.

Figure 4



Press the right turn button to turn the car to the right.

Figure 5



Before starting the car, add water to the car before starting the spray button

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.