



DC Fan Lamp Remote Controller User Manual




Wiring Diagram Of Receiver



Remote Control Transmitter

HVIN:KL448-01



Remote pairing:

1. Turn off the power for 10 seconds.
2. Turn on the power and press the All ON/OFF button immediately within 3s.
3. When hearing 2 sounds like "didi", you can free your hands.

ALL ON/OFF:

Single press the All ON/OFF button, all functions will be turned off and single press the All ON/OFF button again to revert back to previous setting.

Breeze mode:

1. Single Press Breeze Mode/Sleep Mode button. Beep twice to indicate input accepted.
2. Cycle between all speeds at random. Hold each speed for random duration between 20-30 seconds.
3. Stay in mode until cancel condition met: All On/Off, Fan On/Off, Fan speed selected and Reversing.

Sleep mode:

1. Double Press Breeze Mode/Sleep Mode button.
2. Change to lowest dimming setting & lowest fan speed and mute beep.
3. Stay in mode until cancel condition met: All On/Off, Light On/Off, Light Dimming Up/Down.

CCT Cycle:

Press the CCT Cycle button, the light will cycle within 3 different color temperature. When power-on again, the light will memory the last setting.

Mute ON/OFF:

Press Mute ON/OFF button to turn on or off with a beep feedback.

Timer:

Press 1H or 2H or 4H to trigger the timer function and press any non-timing key to cancel the timer.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules and contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.