EXHIBIT 7

INSTRUCTION MANUAL

7.0 <u>Instruction Manual</u>

Attached is a preliminary copy of the Instruction Manual.

The FCC information to user can be found in the last page of this manual.

This manual will be provided to the end-user with each unit sold/leased in the United States.

CONTROLS

- 1. Speaker/Mic Grill
- 2. Push-To-Talk Button
- 3. Signal Code Key
- 4. Volume control ON/OFF Button
- 5. Belt Clip
- 6. Battery Compartment Cover
- 7. Flexible Antenna

FEATURES

- 1-way transmission Walkie Talkies
- Easy control talk button
- Morse code signal button

INTRODUCTION

These Crayola Walkle Talkles are designed with a one-way transmission mode. Easy to operate — fun to usel Just press button to send and release button to receive messages.

BATTERY INSTALLATION

- Open the Battery Compartment Cover (6) of each unit using a screwdriver and insert 1 x "9V" battery. (Make sure that the polarities of the batteries are correctly installed in both units).
- Use only alkaline batteries to protect the life of your Walkie Talkies.
- Replace when sound becomes weak or distorted.

DRAWINGS

OPERATION

- Switch on the Volume controls (4) on both units.
- Press **Push-Ta-Talk button** (2) for transmitting messages. Speak clearly into the speaker microphone.
- You can transmit signals by also pushing Signal Code key (3).
- After talking, release the **Push-To-Talk button** (2). You will then be able to receive transmissions from your other Walkie Talkie.
- NOTE: Always remember to turn the Volume Control ON/OFF button (4) to off position after use.

CAUTION:

To keep your Walkie Talkles in good condition please remember the following:

- a. Do not drop or bang your Walkie Talkies on a hard surface.
- b. **Do not** wet controls or casing and avoid using in areas of high humidity for long periods.
- c. Do not try to separate controls from casing.

ALL WALKIE TALKIES ARE SUBJECT TO ELECTRONIC INTERFERENCE, IF YOU EXPERIENCE PROBLEMS WITH THIS UNIT, STAY AWAY FROM OR TURN OFF: CORDLESS PHONES, BABY MONITORS, INTERCOMS OR ANY OTHER "BROADCAST" DEVICES.

FCC ID: LOUS 41634 ING PERFORMANCE MAY BE AFFECTED BY SURROUNDING STRUCTURES AND EQUIPMENT.

Address : PF Sound Collection

69 Jefferson Street,

Stamford, CT 06902.

Phone 203-358-8100

Art. No. : 541.634

FCC REQUIREMENTS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1.) This device may not cause harmful interference, and
- 2.) This device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications to this unit not expressly approved by the aprty responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced Radio/TV technician for help.

EXHIBIT 8

MISCELLANEOUS INFORMATION

EXHIBIT 7

INSTRUCTION MANUAL

7.0 <u>Instruction Manual</u>

Attached is a preliminary copy of the Instruction Manual.

The FCC information to user can be found in the last page of this manual.

This manual will be provided to the end-user with each unit sold/leased in the United States.

CONTROLS

- 1. Speaker/Mic Grill
- 2. Push-To-Talk Button
- 3. Signal Code Key
- 4. Volume control ON/OFF Button
- 5. Belt Clip
- 6. Battery Compartment Cover
- 7. Flexible Antenna

FEATURES

- 1-way transmission Walkle Talkles
- Easy control talk button
- Morse code signal button

INTRODUCTION

These Crayola Walkle Talkles are designed with a one-way transmission mode. Easy to operate — fun to usel Just press button to send and release button to receive messages.

BATTERY INSTALLATION

- Open the Battery Compartment Cover (6) of each unit using a screwdriver and insert 1 x "9V" battery. (Make sure that the polarities of the batteries are correctly installed in both units).
- Use only alkaline batteries to protect the life of your Walkie Talkies.
- Replace when sound becomes weak or distorted.

DRAWINGS

OPERATION

- Switch on the Volume controls (4) on both units.
- Press Push-To-Talk button (2) for transmitting messages. Speak clearly into the speaker microphone.
- You can transmit signals by also pushing Signal Code key (3).
- After talking, release the Push-Ta-Talk button (2). You will then be able to receive transmissions from your other Walkie Talkie.

NOTE: Always remember to furn the Volume Control ON/OFF button (4) to off position after use.

CAUTION:

To keep your Walkie Talkles in good condition please remember the following:

- a. Do not drop or bang your Walkie Talkies on a hard surface.
- b. Do not wet controls or casing and avoid using in areas of high humidity for long periods.
- c. Do not try to separate controls from casing.

ALL WALKIE TALKIES ARE SUBJECT TO ELECTRONIC INTERFERENCE. IF YOU EXPERI-ENCE PROBLEMS WITH THIS UNIT, STAY AWAY FROM OR TURN OFF: CORDLESS PHONES, BABY MONITORS, INTERCOMS OR ANY OTHER "BROADCAST" DEVICES.

FCC ID: LOUS AT ING PERFORMANCE MAY BE AFFECTED BY SURROUNDING STRUCTURES AND EQUIPMENT.

Address : PF Sound Collection

69 Jefferson Street,

Stamford, CT 06902.

Phone : 203-358-8100

Art. No. : 541.634

FCC REQUIREMENTS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1.) This device may not cause harmful interference, and
- 2.) This device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications to this unit not expressly approved by the aprty responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced Radio/TV technician for help.