



Tnet 210 Module Installation Instructions

FCC ID: NTAT210

**January 13, 2013
Rev 1.0**

PROPRIETARY INFORMATION

ALL RIGHTS RESERVED, NO PARTS OF THIS DOCUMENT MAY BE REPRODUCED, STORED IN RETRIEVAL SYSTEM, OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC, MECHANICAL PHOTOCOPYING, RECORDING OR OTHERWISE WITHOUT THE PRIOR WRITTEN PERMISSION OF TELEMATICS WIRELESS LTD. NOR USED IN WHOLE OR IN PART FOR ANY PURPOSE OR FOR ANY CUSTOMER EXCEPT TELEMATICS WIRELESS.



CAUTION

The User and the Installer should be aware that changes and modifications to the equipment not expressly approved by Telematics Wireless could void warranty and the user's authority to operate the equipment.

Professionally trained personnel should install the equipment.

The antenna used for this transmitter must be installed to normally provide minimum separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter

ATTENTION

The digital portion of the transceiver has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Tnet 210 Module Installation Instructions

Tnet 210 Module is installed on the carrier board and connected to external antenna using special antenna cable.

1. Make sure that the carrier board power is off.



2. Connect Tnet 210 Module to the carrier board using board to board connectors and plastic spacers.



3. Connect antenna cable to the Tnet 210 Module antenna's connector. The antenna cable is specially designed for Tnet 210 Module using female MMCX connector at one end and male TNC connector at the other end.

