

QUICK START GUIDE

Magnetic Power Bank with Holder

Charge π 5H

Official website: www.minthouz.com
Technical support: support@minthouz.com

INTRODUCTION

The Magnetic Power Bank with Holder provides instant charging capabilities, featuring magnetic adsorption that ensures secure attachment and easy alignment for hassle-free charging. Equipped with a foldable holder, it can support your device while charging. Additionally, it offers multiple safety protections: overcharge, over-discharge, over-current, and short circuit protection, ensuring safe and reliable charging. Compact and lightweight, this power bank is perfect for travel and daily use, ensuring your devices stay powered throughout the day.

SPECIFICATION


- Material: ABS+PC
- Battery Capacity: 5000mAh/19.25Wh/3.85V
- Type-C 1 Input: 5V = 2A, 9V = 2A
- Type-C 2 Input: 5V = 3A, 9V = 2A
- Type-C 2 Output: 5V = 3A, 9V = 2.22A, 12V = 1.67A
- USB Output: 5V = 3A, 9V = 2A, 10V = 2.25A, 12V = 1.5A
- USB+Type-C 2 Output: 5V = 3A (Total)
- Wireless Output: 15W-10W-7.5W-5W

IN THE BOX

- 1 × Magnetic Power Bank with Holder
- 1 × USB-C to USB-C Cable (0.3M)
- 1 × Quick Start Guide

- 1 -

OVERVIEW




- ① Type-C 1 ② Type-C 2 ③ USB Output
④ Battery Level + Wireless Charging Indicator
⑤ ON/OFF Button ⑥ Foldable Holder

FEATURE

- Equipped with magnetic adsorption design for secure alignment.
- The foldable holder enables setting devices at comfortable viewing angles, making it ideal for watching videos or conducting video calls.
- Fitted with LED indicators that indicate the remaining battery level, providing a clear visualization of the power bank's charging status.
- Multiple protections ensure the safe charging.
- With a transmission distance of 2-6mm, it can charge your phone easily even with a phone case.
- The compact and lightweight design makes it perfect for easy portability.

- 2 -

LED INDICATOR



- Charge

Battery Level (C/%)	LED1	LED2	LED3	LED4
100%	on	on	on	on
75% ≤ C < 100%	on	on	on	slow flash
50% ≤ C < 75%	on	on	slow flash	off
25% ≤ C < 50%	on	slow flash	off	off
C < 25%	slow flash	off	off	off

- 3 -

- Discharge


Battery Level (C/%)	LED1	LED2	LED3	LED4
75% ≤ C < 100%	on	on	on	on
50% ≤ C < 75%	on	on	on	off
25% ≤ C < 50%	on	on	off	off
3% ≤ C < 25%	on	off	off	off
0% ≤ C < 3%	fast flash	off	off	off
C = 0%	off	off	off	off

NOTE:

- Single-press the button to initiate output and battery level indicator, prioritizing entry into wireless charging mode. If there is no load on the wireless charger after 15 seconds, it switches to power bank mode.
- When wireless charging is activated, the wireless charging indicator is green. When it enters the wireless charging state, the indicator turns yellow.

- 4 -

HOW TO USE



- 5 -

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction