

Network Configuration on Web Page

When you log in to the router for the first time, the installation wizard will appear. Then, follow the steps to configure the network.

Router Mode

1. Welcome

Click Start. The system will check automatically if your router is connected to the Internet.

Welcome to Quantum T2 !

This is Quantum T2,

- Complies with 11n Wi-Fi standard.
- Wi-Fi 600 Mbps speed.
- Provides WEP 64/128-bit, WPA, WPA2 and WPA-Mixed security.
- Supports Guest Network, Media Share, QoS, Parental Control, VPN, WPS etc.
- Supports Smart Roaming for Mobile Client.
- Supports Power Saving, LED Control, System Restart for energy saving.

You can more easily set various functions through web UI and experience fabulous router. Do you want to start the wizard for easy setup?

Start

Note:

- If you want to skip the installation wizard, click **Skip**. This button is available always during installation wizard.
- We recommend you to update the firmware to the latest version when available.

2. Internet Setting

You can connect the Internet automatically or manually depending on your Internet connection type.

Note: This page appears only when your product is not connected to the Internet.

Internet Setting

You can manually configure your connection settings. If you do not know the Internet connection type, please contact your ISP.

Connection Type: **Dynamic IP**

What is the Dynamic IP/Static IP/PPPoE/PPPTP/L2TP? [view more](#)

Previous **Next**

Select the connection type your ISP is using. In most cases, it will be **Dynamic IP**.

- **Dynamic IP:** The Internet will be connected automatically.
- **Static IP:** Enter the IP address, Subnet mask, Gateway and DNS server supplied by the ISP.
- **PPPoE:** Enter the user name and password supplied by the ISP.
- **PPPTP or L2TP:** Enter the user name, password and VPN server supplied by the ISP.

Note: For more information on the Internet connection, refer to the web manual at [www.humaxdigital.com/QUANTUM](#).

If your router is successfully connected to the Internet, the information on the internet connection will display.

Internet Setting

Dynamic IP: 100.1.1.100
WAN IP Address: 100.1.1.100
Subnet Mask: 255.255.255.0
Gateway: 192.168.1.1
Primary DNS: 0.0.0.0
Secondary DNS: 0.0.0.0

Previous **Next**

3. Wireless Network Setting

Enter your own network name and password to change the default settings. You can secure your wireless network from unauthorized users.

Wireless Setting

2.4GHz

Network Name (SSID): **We Love You So Much**

Password: *********

About wireless security and password. [view more](#)

Previous **Next**

4. Password Setting

Enter your ID and password to change the default password. You can enhance the security on your network environment.

Change Password (Optional)

If you change the password, you can make your network more secure. For the default ID and password, see the bottom of the product.

The changed password will be applied from the next login.

Login ID: **admin**

Current Password: *********

New Password: *********

Retype New Password: *********

Previous **Next**

5. Summary

When you complete your network settings, the information on your network will display.

Summary

Internet	Connection Type	Dynamic IP
	IP Address	100.1.1.1
Wireless 2.4GHz	Network Name (SSID)	We Love You So Much
	Password	humax_0000

Previous **Done**

FCC warning:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WISP Mode

You can use wireless Internet service in Router mode.

1. Log in to [dearmyrouter.net](#), and then go to **Management > WISP Mode**.
2. Set the WISP mode to **On**, and select your Internet service provider.

WISP Mode

In this mode, all Ethernet ports are bridged together and the wireless client will connect to ISP access point. The NAT is enabled and PCs in Ethernet ports share the same IP to ISP through wireless LAN.

On/Off: **On**

Select the device and enter the password to connect the host device.

Network Name (SSID)	CH	RSSI	Security	MAC Address	Band
We Love You So Much	1	-45	WPA2-PSK	BC:76:70:7C:5C:74	2.4GHz
TIANA_89	1	-47	WPA2-PSK	F8:D1:15:C8:8A	2.4GHz
ASUS	1	-51	WPA2-PSK	70:7CF8:D1:11:55	2.4GHz
Wafya	3	-26	None	11:5C:54:D8:33:98	2.4GHz
NETGEAR	1	-51	WPA2-PSK	70:7CF8:D1:11:55	2.4GHz
iptime	9	-77	WEP	5C:74:31:ABC:1:D2	2.4GHz

Password: *********

Back **Connect**

2-1. Roaming & Mesh

Just press the WPS buttons on HUMAX products within 1 second. Then, they are connected each other automatically, and configure the mesh network. You will experience seamless Wi-Fi roaming over the mesh network.

Roaming & Mesh Setting

HUMAX each other two products that you want to connect to, you can simply Extended Network via the WPS button. Place the product on where to actual use, press the WPS button on your product.

Tip!
Minimizing the walls, furniture, appliances, etc. to connect between the two products, and the products work best when operating at up to 1.2m (40 feet) inside and outside.

If the existing configured, pressing the WPS button on the Mesh Network products and add new products are the closest connection automatically.

WPS

Start WPS Process...

Previous

2-2. Repeater

If you have a networking device other than HUMAX products, select it from the list and then enter the password. You will experience stronger and wider Wi-Fi signal.

Repeater Setting

Select a device from the list below and enter the password to connect to the host device. Using the WPS button on both devices, you can easily connect them.

If you want to configure the network over a wired Ethernet connection, plug the Ethernet cable into the WAN Port of the host device. In this case, the host operates automatically in Bridge mode.

WPS

Network Name (SSID)	CH	RSSI	Security	MAC Address	Band
IPTime Zone	1	-45	WPA2-PSK	BC:76:70:7C:5C:74	2.4GHz
TIANA_89	1	-47	WPA2-PSK	F8:D1:15:C8:8A	2.4GHz
ASUS	1	-51	WPA2-PSK	70:7CF8:D1:11:55	2.4GHz
Wafya	3	-26	None	11:5C:54:D8:33:98	2.4GHz

Password: *********

Back **Next**

Home

After completing the network settings, go to **Operation Mode**. In this page, you can see the current status of your product.

Home

This page shows the current status and some basic settings of the device.

2.4G

HUMAX

QUANTUM T2

SanULTRA DUAL_1

4 Devices

Internet	Operation Mode	Router Mode
Dynamic IP: 10.10.10.1	Connection Status	Dynamic IP
	IP Address	183.99.19.131
	Subnet Mask	255.255.255.128
	Gateway	183.99.19.129
	DNS Server	168.126.63.1/168.126.63.2
	MAC Address	F4:28:53:35:C3:F9