



WP8333V5 Getting Started Guide

Package Contents


You should have received the following components in your WP8333V5 package.



Mounting the WP8333V5



1. Affix bracket to T- Grid.



2. Rotate bracket to snap on to T- Grid.

3. Place the first mounting post on the rear-side of the device on to the lower notch of the bracket.



4. Rotate the device such that all the mounting posts on the rear-side of the device are snapped in to the respective notches on the bracket.



Getting the WP8333V5 Online

Step 1: Power up

If using PoE, plug one end of the Ethernet cable into the PoE switch or injector and plug the other end into the Ethernet + PoE port (LAN1) on the C-110. Make sure the PoE source you are using is turned ON.


OR

As an alternative to PoE, insert the power adapter plug into an AC power outlet and the other end into the power input port on the unit.

Warning: If powering the device with PoE, ensure that the device is connected to a UL listed indoor PoE source. If not using PoE, ensure that you use only an AC power adapter supported by accessing point (AP).


Step 2: Connect to the network

If you are using PoE, then the unit should already be connected to your network. If you are not using PoE, then plug one end of the Ethernet cable into an Ethernet jack on your network and the other end into the Ethernet port (LAN1) on the unit.



Step 3: Check the LED status

Wait for a few minutes till the LEDs for Power and Ethernet (LAN1) turn solid GREEN, which indicates that the unit is online and operational.



Troubleshooting

LED	Status	Description
Power	Solid Green	Power On
	Off	Power Off
LAN1	Solid Green	Device connected to LAN port 1 at 10/100/1000 Mbps
	Blinking Green	Activity on LAN port 1
LAN2	Solid Green	Device connected to LAN port 2 at 10/100/1000 Mbps
	Blinking Green	Activity on LAN port 2
2.4 GHz	Solid Green	No activity on 2.4 GHz radio
	Blinking Green	Wireless activity on 2.4 GHz radio
5 GHz	Solid Green	No activity on 5 GHz radio
	Blinking Green	Wireless activity on 5 GHz radio
Radio 3	Blinking Green	Activity on third radio

For FCC

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device is restricted for indoor use.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance **22cm** between the radiator & your body.

For IC

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs / récepteurs exempts de licence qui sont conformes au (x) RSS (s) exemptés de licence d'Innovation, Sciences et Développement économique Canada. L'opération est soumise aux deux conditions suivantes:

- (1) Cet appareil ne doit pas provoquer d'interférences.*
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.*

The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

IMPORTANT NOTE:

IC Radiation Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance **28cm** between the radiator & your body.

*Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de **28cm** de distance entre la source de rayonnement et votre corps.*

For JP

5GHz band (W52, W53): Indoor use only (except communicate to high power radio)