


2. Photograph for the worst case configuration



3. Sample Calculation

The emission level measured in decibels above one microvolt (dB μ) was converted into microvolt per meter (μ /m) as shown in following sample calculation.

For example :

	Measured Value at	<u>908.27 MHz</u>	6.4 dB μ / m
+	Antenna Factor		23.0 dB
+	Cable Loss		5.6 dB
	Preamplifier		0.0 dB
	Distance Correction Factor *		0.0 dB
=	Radiated Emission		35.0 dB μ / m
			(= 56.2 μ /m)

* Extrapolated from the measured distance to the specified distance by an inverse linear distance extrapolation.