

## DVDM1020 (EL-708) CIRCUIT DESCRPTION

Driving board : A Block

1. Control TFT dimmer circuit (light sensor switch)
  2. Change 12 DC voltage to AC power ,and supply TFT power. (TFT power 1796-50)
  3. To offer words on TFT (OSD MTL013)
  4. To link and control all functions (UP PROCESSER MTV512MV64)
- 

AV\_SW and FM control board : B lock

1. Command AV\_SW and FM Transmitter signal export .
  2. Receiver car 12 DC voltage inport .
- 

POWER\_KEY and EJECT board : F, C Block

Offer power\_key and eject location.

---

FM TRANSMITTER: K Block

Support Audio FM TRANSMITTER 88.1MHZ ~97.9MHZ , 1 step is 200KHZ

Total : 100 channal from can be choose.

---

AV IN and OUT BOX: D Block

Offer 3 units (Video,Audio) IN and 1 unit (Video,Audio) OUT.