

# RADIO CONTROL CAR MANUAL

( Model: 0998CH )

## **WARNING !**

CHOKING HAZARD-Small parts not for Children Under 3 Years.

Do not play in the rain.

Do not play in the street.

## **VEHICLE (with on-off switch)**

Remove battery cover and install 1\*9.6V power pack (included)

Remove battery pack when not in use

## **FULL FUNCTION 49MHZ TRANSMITTER (with on-off switch)**

With forward/fast forward, reverse, turn left, turn light, stop, reverse left, reverse right function.

Remove battery cover replace 1\*9.6V battery (battery included)

Batteries are to be inserted with correct polarity

## **BATTERY CARE**

For maximum performance, always allow your battery of the tractor to drain before recharging.

Never charge a second time without discharging first. This will affect or damage the battery.

## **BATTERY DISPOSAL**

Do not dispose of the battery in your regular household waste.

Contact your local waste management officials for information on environmentally sound disposal of rechargeable batteries.

If a battery leak develops, avoid contact with leaking fluid. Place the damaged battery in plastic bag for proper disposal.

If fluid comes in to contact with skin or eyes, wash with cool water at least 15 minutes.

## **FCC STATEMENT**

**"Modifications not authorized by the manufacturer may void users authority to operate this device"**

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.