

Instructions

Insert the Remote Base's 3-prong plug into a grounded outlet. If using outdoors, be sure to plug in a GFI approved outlet. Plug appliance into located on bottom of Remote Base. Using the Wireless Remote Control. Press ON button to activate device.

Battery Replacement

Use 23A 12volt battery (L1028). To replace, screw off back cover on back of Wireless Remote Control. Do not dispose of batteries in fire. Batteries may explode or leak

Caution

Let the switch hang downward so moisture doesn't accumulate in the outlet. Install cord and unit above ground level with the receptacle in downward minimum twice vertical length of this unit positioned. Suitable for damp locations. Not for water immersion or for use were directly exposed to water. Store indoors when not in use. Red indicator light is lit when the outdoor receiver/switch is on.

DO NOT splice , repair or modify. Unplug when not in use. Fully insert plug. DO NOT use damaged remote sets. Inspect periodically. Use within the electrical rating marked on the remote set. DO NOT plug more than a total 1,000 watts in this remote set. If watts are not marked on appliance, multiply ampere rating(on nameplate) by 125 to determine equivalent watts. Add determined watts for each plugged-in appliance or lamp (sum of watts on bulbs) to find total watts being used. Operating temperature range -30C (-22F) to 45C (113F).

FCC warning

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

Repair Center in North Africa

The NCC Inc.

Brooklyn, NY

1 800 730 3707