

FROK BLUETOOTH HEADSET

QUICK START GUIDE



Model No: BT001

1. Technical Specifications

| | |
|-----------------------------|---|
| Operating Frequency Band | 2.4GHz – 2.48GHz unlicensed ISM Band |
| Bluetooth Specification | Version 1.1 |
| Supported Profiles | Headset |
| Output Power Class | Class 2 |
| Battery Used | ATL 402030 – 150 mAh (Rechargeable Lithium Polymer) |
| Battery Voltage | 3.7Vdc |
| Charger | 5.0V – 5.8V (typ. 260mA) |
| Talk Time | 4 hours (based on HV3 packets) |
| Standby Time | Up to 130 hours |
| Battery Charging Time | 2 hours |
| Range of Operation | Up to 10 meters |
| Dimension | TBA |
| Visual Indication | Dual colour LED (Green and Red) |
| Number of Operating Buttons | 2 Volume Control Buttons and 1 Multi Function Button |
| Type Approval | FCC, CE Mark, BQB |

2. Getting Started

2.1 Switching Headset On and Off

Switch On

To switch on headset, press and hold the TALK button for at least 5 seconds. Release the TALK button immediately when LED is flashing Green every.

Switch Off

To switch off headset, press and hold the TALK button for at least 5 seconds. Release the TALK button immediately when LED is flashing Red rapidly.

2.2 Pairing with Bluetooth Phone

Before Bluetooth headset can be used with Bluetooth phone, it is required to perform pairing operation with the Bluetooth phone. Please refer to the instruction manual of the Bluetooth phone.

To prepare the Bluetooth headset for pairing with the Bluetooth phone, the headset must be off. Press and hold the TALK button for at least 10 seconds. Release the TALK button when LED is flashing RED and GREEN alternatively. The headset is now ready for pairing with the Bluetooth phone. Bluetooth phone has to initiate discovery and select the Bluetooth headset for pairing. Enter the passkey “1234” of the Bluetooth headset to pair headset with phone. After pairing is successful, the Bluetooth headset LED will flash GREEN every few seconds.

3. Operating Instructions

3.1 Answering Call with Bluetooth Headset

Answering Call

When an incoming call is received on the Bluetooth phone that has been paired with headset, a ring tone will be heard on the headset earpiece after a few seconds. Press the TALK button to answer the incoming call.

Changing Headset Earpiece Volume

Press the Vol+ to increase the volume and Vol- to decrease the volume. This operation is only active during call operations.

Mute Headset Microphone

Press and hold Vol+ or Vol- during an active call to temporary mute the microphone. Release the Vol+ or Vol- button only after a periodic tone is heard to indicate the mute function is active. To disable the mute function, again press and hold the Vol+ or Vol- button until the periodic tone is turned off.

Ending a Call

To hang up an active call, press the TALK button.

Making a call using Voice Dial

Make sure that the Bluetooth phone has enabled its voice dial function before use. To initiate Voice Dial, press the TALK button. Wait for a beep sound then speak the name of the party you wish to call.

Charging the Headset

When the Headset battery is running low, LED will flash RED every few seconds. To charge the battery, turn on the power to the DC adapter and connect the DC adapter to the headset. LED will turn RED to indicate charging is in progress. LED will be off after the headset battery is fully charged.

Please note that headset will not function during battery charging operation.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:**FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.