



Operation Instructions

The following is the operational instruction for your IPLink1220.

- 1) Install the IPLink on your board
- 2) Using your installation CD, install the Helicomm IP-Software into your computer.
- 3) Apply power to your module.
- 4) Via your interface cable connect the IPLink to the computer.
- 5) Down load the firmware into your module.

“ This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.”

- 6) Label your device with “Contains FCC ID: RF2IPLINKP220”

CAUTION:

The user is cautioned not to modify or change the IPLink1200 without explicit approval from Helicomm. If the user does not comply, authority to operate the equipment will be void.

INFORMATION TO USER

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

HUMAN EXPOSURE STATEMENT

This information is necessary to ensure that equipment installers, operators and users are made aware of the dangers of exposure to radio frequency radiation and that the Module shall be installed and operated in compliance with 47 CFR Part 15, Subpart C of the FCC Rules and Regulations.

In all applications and uses, compliance with current FCC RF regulations limiting human exposure to radio frequency exposure is dependent upon installation, operation and use of the equipment in accordance with all instructions provided