




# RAZER RZ03-0236 WIRELESS KEYBOARD

IMPORTANT PRODUCT INFORMATION GUIDE

## WHAT'S INSIDE

- Razer RZ03-0236



- A. Bluetooth profile keys
- B. Task View / Mission Control key\*
- C. Volume control keys
- D. Screen brightness keys
- E. Backlight control keys
- F. Keyboard mode switch
- G. Power indicator
- H. USB Type C port
- I. Screen lock key
- J. Media control keys
- K. Mute / Unmute microphone key
- L. Copilot key\*\*

\*To use on macOS devices, switch the keyboard layout by pressing Fn + Tab.

\*\* Copilot is exclusively available on Windows 11. Available features may vary on selected markets. Find out more at [microsoft.com/windows/copilot-ai-features](https://microsoft.com/windows/copilot-ai-features). For Windows 10, this key functions as a context menu key.


- USB Type C to Type C cable



- Important Product Information Guide

---

## WHAT'S NEEDED



Windows® 10 64-bit  
(or higher)

USB Type C

OR



---

## LET'S GET YOU COVERED




Register your product and score exclusive benefits

[razerid.razer.com/warranty](http://razerid.razer.com/warranty)

*Your product's serial  
number can be found*

## GETTING STARTED

### CHARGING YOUR KEYBOARD




**i** For best results, fully charge your keyboard before using it for the first time. You may continue using the keyboard while plugged in.

### CONNECTING TO YOUR KEYBOARD


#### A. Via Bluetooth mode

1.







2.

Press and hold for 5s to activate  
Bluetooth pairing mode




**i** The corresponding Bluetooth profile button will show which profile is in pairing mode. Your keyboard can pair up to 3 devices using its Bluetooth profiles.

3.



Your keyboard is now ready to use in Bluetooth mode.


### Switching between Bluetooth profiles




*The corresponding Bluetooth profile button will show which profile is active.*

## B. Via Wired mode

1.




2.



*When in Bluetooth mode and connected to a system, the keyboard will only charge.*


## USING YOUR RAZER RZ03-0236

### SWITCHING BETWEEN KEYBOARD LAYOUTS



**i** *Keyboard layout lighting sequence will only be displayed briefly across F1 to F3 keys.*

### LOW POWER INDICATOR



**i** *This lighting sequence will repeat until the keyboard is charged or its battery is drained.*

### CYCLING THROUGH ONBOARD MEMORY PROFILES

Right alt key

The diagram shows the key combination for cycling through onboard memory profiles. It consists of three icons: a 'fn' key icon with a globe symbol, a green plus sign (+), and an 'alt' key icon with 'cmd' below it. Below the 'fn' icon is the text 'Press and hold'. Below the 'alt' icon is the text 'Press\*'. Above the icons is the text 'Right alt key'.

Profile	Profile 1	Profile 2	Profile 3	Profile 4	Profile 5
Button color	White	Red	Green	Blue	Cyan


*\*Repeat until desired profile is*

- i** *To view the active onboard memory profile, hold down the fn key, and the right alt key will light up according to the active profile. Onboard memory profiles can be customized via Razer Synapse.*

## KEYBOARD FUNCTIONS

Hotkey	Function
F4 (昌□)	Open Mission Control to display an overview of all open windows and spaces on a Mac.
F5 / F6 / F7 (🔊 / 🔋 / 🔋×	Adjust or mute the audio volume
F8 / F9 (☀️ / ☀️)	Decrease or increase the screen brightness.
F10 / F11 (⌨️ / ⌨️)	Adjust the keyboard's brightness

## CHROMA EFFECTS



Hotkey	Chroma effect
fn + ctrl + 1	 Off
fn + ctrl + 2	 <b>Static*</b>
fn + ctrl + 3	 <b>Breathing*</b>
fn + ctrl + 4	 <b>Spectrum cycling</b>

*\*Press again to change color.*

- i** Use the Razer Synapse app to customize your keyboard's lighting effects and access other

*advanced features available on your keyboard.*

---

## SAFETY AND MAINTENANCE

### SAFETY GUIDELINES

To achieve maximum safety while using your Razer RZ03-0236, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to [support.razer.com](https://support.razer.com) for support.

Keep the keyboard and all its parts and accessories out of the reach of small children to avoid accidents and/or injuries.

Don't take apart the device, and do not attempt to operate it under abnormal current loads. Doing so will void your warranty.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device to let the temperature stabilize to an optimal level.

### COMFORT

Research has shown that long periods of repetitive motion, improper positioning of your computer peripherals, incorrect body position, and poor habits may be associated with physical discomfort and injury to nerves, tendons, and muscles. Below are some guidelines to avoid injury and ensure optimum comfort while using your Razer RZ03-0236.

1. Position your keyboard and monitor directly in front of you with your mouse next to it. Place your elbows next to your side, not too far away, and your keyboard within easy reach.
2. Adjust the height of your chair and table so that the keyboard and mouse are at or below elbow height.
3. Keep your feet well supported, posture straight, and your shoulders relaxed.
4. During gameplay, relax your wrist and keep it straight. If you do the same tasks with your hands repeatedly, try not to bend, extend or twist your hands for long periods.
5. Don't rest your wrists on hard surfaces for long periods.

6. Use a wrist rest to support your wrist while gaming.
7. Customize the keys on your keyboard to suit your gaming style and minimize repetitive or awkward motions.
8. Don't sit in the same position all day. Get up, step away from your desk, and do exercises to stretch your arms, shoulders, neck, and legs.

If you should experience any physical discomfort while using your keyboard, such as pain, numbness, or tingling in your hands, wrists, elbows, shoulders, neck or back, please consult a qualified medical doctor immediately.

## MAINTENANCE AND USE

The Razer RZ03-0236 requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you unplug and switch off the device from the computer and clean it using a soft cloth or cotton swab to prevent dirt buildup. Don't use soap or harsh cleaning agents.

## BATTERY WARNING

The Razer RZ03-0236 contains a Li-ion rechargeable battery. In general, the life expectancy of such batteries is dependent upon usage. If you suspect that the Li-ion rechargeable battery inside the Razer RZ03-0236 may be drained (has a low charge), try charging it.

**Caution:** Don't open, mutilate, or expose to conducting materials (metal), moisture, liquid, fire, or heat. Doing so may cause batteries to leak or explode, resulting in personal injury. Battery life varies with usage.

---

## LEGALESE

### COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2025 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks are the property of their respective owners.

Apple, macOS, Mission Control and Spotlight are trademarks of Apple Inc., registered in the U.S. and other countries and regions.

Windows and the Windows logo are trademarks of the Microsoft group of companies.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Razer is under license.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer RZ03-0236 (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

### LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit [razer.com/warranty](https://razer.com/warranty).

### LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

### GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

## **Caution!**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **Canada Statement**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.


(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## **Declaration of Conformity**

Hereby, Razer Inc. 9 Pasteur. Irvine. CA 92618, USA declares that the radio equipment type Wireless Keyboard RZ03-0236 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: [razer.com/legal/compliance](http://razer.com/legal/compliance)



#### BATTERY CHARGING INFORMATION

The power delivered by the charger shall be between min 8.5 Watts required by the radio equipment, and max 15 Watts in order to achieve the maximum charging speed.

- 1) Operating frequency: 2402-2480MHz
- 2) Radio power: 4dBm