

Garden Speaker Operating Instruction (for FCC approval process) 12/02/06

Power Unit Battery Installation

1. Please shut the power, Then unscrew the top cap from 'close' to 'open'.
2. Insert 5 'AA' batteries, Follow the polarity indications inside the compartment and be sure to install batteries as indicated.
3. Screw the top cap from clockwise till the indicators in one level.

Operating the Unit

NOTE: The unit can be operated either with the control buttons located on the top of the power unit or with the remote control.

1. According to the indications to match the channel and the sound channel.
2. Cut into the garden soil from tip, and keep stable.
3. Press on/off power button on the top of the unit upon, the indicator light will be on.

After doing above all, the unit can work on finely

Transmitter Battery Installation.

1. Open the battery door on the back of unit.
2. Insert 3 'AAA' batteries, follow the polarity indications inside the compartment and make sure to install the batteries as indicated.
3. Close the battery door as the same before.

Transmitter Synchronization

1. The frequency between main unit and transmitter has been synchronized at the factory. However, if the transmitter does not work properly, please perform the following:
2. Install fresh batteries in the transmitter and power unit.
3. Press the Power button on the main unit so it is ON. The LED indicator will light.
4. Slide the up & down button to CH1 on top of the transmitter unit when keep the button CH1 as the indication on the top of operation pan covered by the top cap. And CH2 on the transmitter unit should match the CH2 on the master unit.
5. This procedure should synchronize the transmitter and the power unit.

NOTE: Please turn off the power when finish the musical performance on the master unit.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.