


**Test setup photos of EUT**


## 1. Orthogonal planes of EUT

- The testing was set in the three orthogonal planes and measured for each position (X, Y, Z).


### A. X- axis



### B. Z-axis



## C. Y-axis




## 2. Worst case of orthogonal planes each frequency band


- Test setup photos for each mode were reported as representative worst axis after radiated measurements for each position were complete.

### 2.1. WLAN, GSM850, WCDMA850, LTE Setup photos


#### A. Radiated Spurious Emission without charger (Below 30 MHz)




#### B. Radiated Spurious Emission without charger (30 MHz – 1 GHz)




## C. Radiated Spurious Emission without charger (Above 1 GHz)




## D. Radiated Spurious Emission with charger (Below 30 MHz)




## E. Radiated Spurious Emission with charger (30 MHz – 1 GHz)



## F. Radiated Spurious Emission with charger (Above 1 GHz)




## G. AC Power Line Conducted Emission (WLAN)




## 2.2. GSM1900, WCDMA1900 Setup photos

### A. Radiated Spurious Emission without charger (Below 30 MHz)




### B. Radiated Spurious Emission without charger (30 MHz – 1 GHz)







## C. Radiated Spurious Emission without charger (Above 1 GHz)




## D. Radiated Spurious Emission with charger (Below 30 MHz)



## E. Radiated Spurious Emission with charger (30 MHz – 1 GHz)




## F. Radiated Spurious Emission with charger (Above 1 GHz)



## 2.3. BT Setup photos

### A. Radiated Spurious Emission without charger (Below 30 MHz)




### B. Radiated Spurious Emission without charger (30 MHz – 1 GHz)




## C. Radiated Spurious Emission without charger (Above 1 GHz)




## D. Radiated Spurious Emission with charger (Below 30 MHz)




**E. Radiated Spurious Emission with charger (30 MHz – 1 GHz)**



**F. Radiated Spurious Emission with charger (Above 1 GHz)**




## G. AC Power Line Conducted Emission




## 2.4. BT LE Setup photos

### A. Radiated Spurious Emission without charger (Below 30 MHz)




### B. Radiated Spurious Emission without charger (30 MHz – 1 GHz)



## C. Radiated Spurious Emission without charger (Above 1 GHz)




## D. Radiated Spurious Emission with charger (Below 30 MHz)






**E. Radiated Spurious Emission with charger (30 MHz – 1 GHz)**



**F. Radiated Spurious Emission with charger (Above 1 GHz)**




## G. AC Power Line Conducted Emission




## 2.5. NFC Setup photos


### A. Radiated Spurious Emission without charger (Below 30 MHz)




### B. Radiated Spurious Emission without charger (30 MHz – 1 GHz)



**C. Radiated Spurious Emission with charger (Below 30 MHz)**



**D. Radiated Spurious Emission with charger (30 MHz – 1 GHz)**



## E. AC Power Line Conducted Emission

