

# BOOKLET STYLE, FULL COLOR

## 8. BACK COVER

©2017 Zeikos, Inc. iHip is a trademark of Zeikos, Inc. All Rights Reserved. All other trademarks and trade names are those of their respective owners. United States and international patent pending. The illustrated product and specifications may differ slightly from that supplied. Designed by iHip, Manufactured in China. For ages 12+. This is not a toy.

**WARNING:** Under Prop65, this product may expose you to chemical(s) which are known to the State of California, to cause cancer and birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

Limited One Year Warranty.

[www.iHip.com](http://www.iHip.com)

 19 Progress St. Edison, NJ 08820

## 1. COVER



# BLITZ BALL WIRELESS SPEAKER

WMBLITZSPKR

## INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY  
AND RETAIN FOR FUTURE USE

## PAGE 2.

### GETTING STARTED

- Remove the unit from the box.
- Remove any packaging from the product.
- Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

### FEATURES

- 2.1 Channel Bluetooth Speaker
- Built-in Rechargeable Battery

### PACKAGING CONTENTS

- Bluetooth Indoor & Outdoor Portable Party Speaker
- USB Charging Cable
- Instruction Manual

### TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
Low Sound Level	Source (Tablet, Mobile Phone, Laptop, etc.) volume too low.	Adjust source volume.
	Battery dead.	Charge battery.
Sound Distorted	Battery nearly dead.	Charge battery.
	Source (Tablet, Mobile Phone, and Laptop) turned off.	Turn the source on.
	Speaker turned off.	Turn the speaker on.
No Sound At All	Volume turned down source.	Adjust volume source.
	Media paused on source.	Play media from source.



This appliance should not be put into the domestic garbage at the end of its useful life, but must be disposed of at a central point for recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

Made in China

## PAGE 6.

### Specification

Material:	PU+ABS
Speaker:	5W dia:50mm 4Ω
Li-Battery:	3.7V(1200mA)
Frequency range:	90Hz-20KHz
S/N:	>75dB
Transmission range:	30 meters (approx. in the open space)
Bluetooth:	V4.2 + EDR
Play time:	up to 2 hours (approx.)
Charge Voltage:	DC 5V

**Note:** In order to have better battery life, please do not charge for more than 6 hours.

Overcharging the speaker can adversely impact the battery life.

### IMPORTANT SAFETY INFORMATION

- Read all instructions before using this product.
- Do not use if unit has been damaged in any way.
- Repairs to electrical equipment should only be performed by qualified persons. Improper repairs may place user at serious risk.
- Place unit on sound, even surface, free of vibrations and away from sources of heat.
- Do not put objects into openings.
- Keep free of dust, lint, hair, etc.
- Do not use this unit for anything other than its intended use.
- Keep this product out of reach of children.
- Do not play music at excessive levels especially near children, as damage to hearing may occur.

## PAGE 4.

### INSTRUCTIONS FOR USE

#### Charging the Speaker

- Connect the USB cord (included) to the charging port of the speaker and insert the other end into a port on your computer or similar power source.
- **Red LED** turns on indicating that the battery is being charged. Once it is fully charged, the **Red LED** will turn off. It takes nearly 4 to 5 hours to fully charge the Battery.

**Note:** In order to have better battery life, please do not charge for more than 6 hours. Overcharging the speaker can adversely impact the battery life.

#### Turn On/Off the Speaker

- To turn "ON" the speaker, press the "POWER" button.
- To Turn "OFF" the speaker, press the "POWER" button again.

#### Turn the Speaker to Bluetooth Pairing Mode


- Turn "ON" the speaker.
- You would hear the beep tone and see the LED light blinking steadily. The speaker is now in pairing mode.

**Note:** Speaker will automatically pair with previously paired devices.

### LISTENING TO MUSIC WIRELESSLY

Please ensure that your device (iPhone;Tablet or Other Smart Phone) is paired with the Blitz Ball to stream music wirelessly. Once it is paired, play music from your device.

PAIRING NAME: BLITZ BALL



## PAGE 5.

## FCC Information

This device complies with Part 15 of the FCC rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.